


A430S AURORA POST GRILL REPLACEMENT PARTS LIST

To order replacement parts, contact your local Fire Magic® dealer.



Some items shown are optional, or are not available for certain models. Your model may vary, refer to parts table.

AURORA GRILL REPLACEMENT PARTS LIST (cont.)

Item	Description	A430s	
		Part No.	Qty.
1.	Stainless cooking grid (set of 2)	3542-DS-2	1
2.	Flavor grid (set of 2)	3063-S-2	1
3.	Main burner	3042-50	2
4.	Flame arrester kit	24177-05	2
5.	Silicone gasket	24177-06	2
6.	Infrared burner assembly *	3065A	1
7.	Infrared radiant protective screen *	3060-02A	1
8.	Infrared electrode assembly *	3199-80	1
9.	Oven lid w/ oven thermometer	23729-60	1
10.	Oven lid spring ‡	23729-71	1
11.	Warming rack	3672S-B	1
12.	Backburner*	24130-11H	1
13.	Backburner cover*	24148-010	1
14.	Patio base w/ hardware *†	24330-31	1
or	In-ground base w/ hardware *†	24330-32	1
15.	Heavy-duty rotisserie motor*	3600-02	1
16.	Heavy-duty rotisserie rod*	3603-30	1
17.	Rotisserie knob*	24187-16	1
18.	Meat holder (pair)*	3613	1
19.	Counterbalance*	3620E	1
20.	Grid lifter	3519	1
21.	Convertible regulator	PR-4	1
22.	Valve manifold w/ backburner	24130-22	1
or	Valve manifold w/o backburner	24130-28	1
23.	Control panel w/ backburner	24130-49	1
or	Control panel w/o backburner	24130-50	1
24.	Small knob *	24182-42	1
25.	Large knob	24182-41	2
26.	LED disk (small)*	24182-64	1
27.	LED disk (large)	24182-63	2

Item	Description	A430s	
		Part No.	Qty.
28.	Oven lid thermometer w/ bezel ‡	23307	1
29.	Drip tray	3084	1
or	Drip tray w/ match holder	3085	1
30.	Drip tray liner (set of 4)	3557	1
31.	Rigid shelf (left)	24330-017L	1
32.	Rigid shelf (right)	24330-017R	1
33.	Patio mount hardware kit w/ lag shield and lag screw (if applicable)	24330-25	1
34.	Timer valve (1 hour)	3092B	1
35.	Propane regulator / hose assy. *‡	5110-07	1
or	Natural Gas QD hose *‡	5110-03	1
36.	Wire harness assembly‡	24177-29	1
37.	Backburner electrode*‡	4199-52	1
38.	Main burner electrode‡	3199-72	2
39.	Natural gas orifice(s)‡	3001-42-2	1
40.	Natural backburner gas orifice(s)‡	3001-52-1	1
41.	Propane gas orifice(s)‡	3001-54-2	1
42.	Propane backburner gas orifice(s)‡	3001-59-1	1
43.	Wire harness extension	24182-53	1
44.	Power supply box w/ cord	24182-18	1
45.	12V / 10 watt halogen light bulb ‡	24187-15	2
46.	Light lens ‡	24187-26	2
47.	Lamp assembly ‡	24187-28	2
48.	Light switch	24182-48	1
49.	Backburner flex connector *‡	3030-01	1
50.	Lighting tube (left) ‡	24187-29	1
51.	Lighting tube (right) ‡	24187-35	1
52.	Air baffle	24194-40	1

* If equipped

† For replacement only (not conversion)

‡ Not shown