

step 4 PLACEMENT

Place the SIB-106 on a flat, level surface, (table, workbench, etc.). Keep lights 6"- 8" away from surface of soft lighting box for best light diffusion. **To conserve battery life, always turn off lights when not in use.**



step 5 STORAGE

The soft lighting box folds into a case for traveling and protection. The background, lights and camera stand are stored in their own individual compartments. **CAUTION: ALLOW LIGHTS TO PROPERLY COOL OFF BEFORE HANDLING OR STORING.**



ACCESSORIES

DUAL SIDED BACKGROUNDS

Model No.: PHO-3011 Blue/Grey
 Model No.: PHO-3012 Black/White
 Model No.: PHO-3013 Green/Purple
 Model No.: PHO-3014 Red/Yellow

12" TURNTABLE

Model No.: PHO-4001

REPLACEMENT LAMP

LED-36-1001

DC POWER SUPPLY

LED-36-1002

PHOTO TIPS

This system utilizes energy-efficient, compact fluorescent daylight temperature bulbs. We recommend not using the camera's "AUTO" mode setting. Best color is achieved using the "MANUAL" mode and setting the camera's white balance to "FLUORESCENT" with the flash setting "OFF". (READ YOUR CAMERA'S INSTRUCTION MANUAL FOR MORE DETAILS)

Place object in the center of Soft Lighting Tent for the very best diffused light.

For best definition, use a background color that creates contrast. Avoid placing objects directly on background since this will create micro-shadows which reduce edge definition. Raise object at least 1/2" off surface for shadow-free edges.

Use the "MACRO" setting (usually a flower symbol) for close-ups. Never use digital zoom - optical zoom only.



PHOTO STUDIO IN-A-BOX®



Always consult your local municipality for the proper disposal of used LED lamps.

RoHS



American Recorder Technologies, Inc.
 1872 Angus Ave., Simi Valley, CA 93063 - USA
 Toll Free: 888 611-3790 · Voice: 805 527-9580 · Fax: 805 527-1433
 info@americanrecorder.com · www.americanrecorder.com

Congratulations on your purchase of the SIB-106 PHOTO STUDIO IN A BOX. The SIB-106 is compatible with all formats of digital imaging and will provide an effective and professional lighting environment for small and medium size objects. The SIB-106's compact size and light weight make it ideal for quick set-ups and traveling. We recommend you read these instructions before use.



IMPORTANT SAFETY PRECAUTIONS

Use only as intended. Should only be used by qualified individuals.
CAUTION: For indoor use only. Use in dry, ventilated area free of excessive dust, humidity, flammable materials, corrosive fumes and conductive contaminants. Do not plug LED lights into any power source other than AMERICAN RECORDER power supply.

KEEP THIS PRODUCT OUT OF THE REACH OF CHILDREN

Keep Soft Light Box folded and stored in a dry area when not in use. Use only a dry cloth to clean the soft lighting box panels. Never use abrasives or solvents.


The information contained in this document is subject to change without notice. American Recorder Technologies, Inc. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Not liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

WARRANTY


AMERICAN RECORDER TECHNOLOGIES, INC. (ART) includes with this product a limited one year guarantee, free from defects in manufacture and workmanship to the original owner. Warranty does not apply to misuse, abuse, neglect, accident, improper use, etc. **ART** reserves the right to make such determination on the basis of factory inspection.

A valid return authorization number must be obtained from **ART** customer service department for all factory warranty service. All warranty repairs must be returned prepaid. (COD's will be refused).


step 1 SOFT LIGHTING BOX



Open the soft lighting box



Attach background to fasten strip






Fold up sides and fasten straps

step 2 LIGHTS

LED lights require 3 each "AAA" batteries (not included)

Carefully depress latch and open battery cover. Insert batteries and replace cover

Extend feet from handle and place light on flat surface or use as a hand-held light



Place lights a minimum of 6" away from sides of soft lighting box. For best results, aim lights towards middle of panels. This will allow for even light diffusion and minimal shadows.

WARNING: CONSERVE BATTERY LIFE - LIGHTS SHOULD ONLY BE "OFF" WHEN NOT PHOTOGRAPHING!

step 3 CAMERA STAND



Bolt leg to telescopic arm



This camera stand is for use with compact cameras only.

Remove camera mount from shoe and thread to camera, place in shoe then lock.




Camera Mount



Use swivel ball and angle arm to adjust camera position.

To adjust telescopic arm, flip out release lock. After adjusting arm, engage flip lock.



LOCK

UNLOCK