




ELIE BLEU
PARIS

HOW TO CARE FOR YOUR HUMIDOR

1ST Seasoning of Humidor






1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Make sure

they're open

by sliding


both buttons

1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Fill the

Humidifiers

with some


distilled water

1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Let the Humidifiers

rest upside down

until all the

excess water

has dripped out

1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Once they've

stopped leaking,

put the open

Humidifiers

back in the


Humidor

1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Close the Humidor

and let it rest

for 2 to 3 days

(according to

room temperature


& humidity)

1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Repeat until

the Hygrometer

indicates

a humidity level

between

60% & 75%

1ST Seasoning of Humidor




1ST Seasoning of Humidor

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Your Humidor

is ready


for your Cigars

How to change your hygrometer

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Rotate the

Hygrometer

while pulling

it out

How to change your hygrometer

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Place the new

Hygrometer

by simply


pushing it

How to change your hygrometer

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Your Humidor

Hygrometer

is replaced

CARE INSTRUCTIONS

CARE TIPS

1st SEASONING


CHANGE HYGROMETER



Keep away

from any

heat source




CARE INSTRUCTIONS

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Clean the

varnished

surface with

a cloth and

diluted alcohol


or glass cleaner

CARE INSTRUCTIONS

CARE TIPS

1st SEASONING

CHANGE HYGROMETER



Never use

water

inside the

Humidor