



## Brief Description E034

### **What is E034?**

If your electric bike screen says E034, it means there's something funky with the throttle.

### **why does it occur?**

Usually, it's either the throttle sensor acting up or it's not hooked up right. Lots of things can cause this, like hiccups during manufacturing or damage from a rough ride.

## **Troubleshooting**

Here's what you can try:

### 1. Throttle Sensor Wire Connection Error

Check the throttle sensor wire. Unplug it, then plug it back in. If the E034 message disappears, it was probably just a bad connection. Easy fix, just make sure everything's snug.

### 2. Throttle Damage

If the E034 message sticks around even after you've checked the wire, it's likely the throttle itself is busted. No worries, though! Just reach out to our customer service team, and we'll send you a new throttle.