

# BDI Equipments BD-07

INTERVALS	ITEMS
Every 50 hours	Check of fuel pipes and clamp bands
See NOTE	Change of engine oil
Every 100 hours	Cleaning of air cleaner element
	Cleaning of fuel filter
	Check of battery electrolyte level
	Check of fan belt tightness
Every 200 hours	Check of radiator hoses and clamp bands
	Replacement of oil filter cartridge
	Check of intake air line
Every 400 hours	Replacement of fuel filter element
Every 500 hours	Removal of sediment in fuel tank
	Cleaning of water jacket (radiator interior)
	Replacement of fan belt
Every one or two months	Recharging of battery
Every year	Replacement of air cleaner element
	Check of damage in electric wiring and loose connections
Every 800 hours	Check of valve clearance
Every 1500 hours	Check of fuel injection nozzle injection pressure
Every 3000 hours	Check of turbo charger
	Check of injection pump
	Check of fuel injection timer
Every two years	Change of radiator coolant (L.L.C.)
	Replacement of battery
	Replacement of radiator hoses and clamp bands
	Replacement of fuel pipes and clamps bands
	Replacement of intake air line