

# BDI Equipments BD-4A

INTERVALS	ITEMS
Every 50 hours	Check of fuel pipes and clamp bands
See NOTE	Change of engine oil (depending on tjhe oil pan)
Every 100 hours	Cleaning of air cleaner element
	Cleaning of fuel filter
	Check of battery electrolyte level
	Check of fan belt tightness
Every 200 hours	Check of radiator hoses and clamp bands
	Replacement of oil filter cartridge (depending on the oil pan)
	Check of intake air line
Every 400 hours	Replacement of fuel fitler element
Every 500 hours	Removal of sediment in fuel tank
	Cleaning of water jacket (radiator interior)
	Replacement of fan belt
Every one or two months	Recharging of battery
Every year or every 6 cleanings of air cleaner element	Replacement of air cleaner element
Every 800 hours	Check of valve clearance
Every 1500 hours	Check of fuel injection nozzle injection pressure
Every 3000 hours	Check of turbo charger
	Check of injetion pump
	Check of fuel injetion timer
Every two years	Replacement of battery
	Replacement of radiator hoses and clamp bands
	Replacement of fuel pipes and clamps
	Change of radiator coolant (L.L.C.)
	Replacement of intake air line