



How to prepare images for decals.

When Preparing images for photo decal paper, please consider the following. Leave at least 1cm around the edge and at least 2.5cm at the bottom of the page. This will prevent you losing any edges of the images in formatting.

The images are printed in black and white and turn sepia once fused.

What works best?

Silhouettes, Line drawings, Maps, Text, High Contrast Photos (grey scale)



TEXT Text **TEXT** Text **Text** T

Text Text

What won't work?

Soft photos with little contrast, Images with a grey background, Poor or pixelated images

