



The
INDOOR
GOLF *Shop*™

SIG8

ENCLOSURE

Assembly Guide



THANK YOU

We appreciate you choosing us for your indoor golf needs, and specifically for your purchase of the SIG8 enclosure and impact screen. We know you will enjoy this quality product.

You will find everything you need to complete the assembly of your new enclosure in this guide. You will also find a few helpful tips along the way that our team of experts has provided to ensure that you have the best indoor golf experience possible.

We are here for you and happy to help!



TABLE OF CONTENTS

SPECIFICATIONS	1
SAFETY INSTRUCTIONS	2
WHAT'S INCLUDED	3
OVERVIEW OF SIG8 ENCLOSURE	4
FRAME ASSEMBLY	5-11
ENCLOSURE ASSEMBLY	12-17





SPECIFICATIONS

PRODUCT NAME	SIG8 ENCLOSURE
ENCLOSURE DIMENSIONS	(H) 8'4" x (W) 8'4" x (D) 13'7"
RECOMMENDATIONS	A STEP-STOOL OR LADDER WILL BE NEEDED DURING ASSEMBLY.
	IT IS RECOMMENDED THAT AN ADDITIONAL PERSON ASSIST IN THE ASSEMBLY OF THIS ENCLOSURE.
WEIGHT	110 LBS.
COLOR	BLACK SURROUND/FRAME WHITE IMPACT SCREEN
SCREEN VIEWABLE DIMENSIONS	(W) 7'7" x (H) 7'7" x (DIAG) 10'8"
RECOMMENDED SPACE REQUIREMENTS	MINIMUM OF 10' WIDTH, 16' LENGTH, AND 9' CEILING HEIGHT




SAFETY INSTRUCTIONS

- Please pay close attention and make sure children, pets, and other spectators are at a safe distance when swinging a golf club inside the enclosure.
- Additionally, take every precaution to protect ceilings, walls, windows, vehicles, and neighboring homes.
- Be alert of where you stand and walk, especially when others are swinging golf clubs or hitting balls into the screen.
- Make sure the setup is far from gas lines, electric heaters, fireplaces, candles, or any other source of heat or fire hazard.
- When not in use, store neatly in a cool, dry location, and protected from weather elements and direct sunlight.
- The Indoor Golf Shop is not responsible for any damage to property and/or any personal injury.
- Be mindful of disconnected and falling pipe if not snapped/tightened properly.
- Do not hang from the enclosure.



WHAT'S INCLUDED

SIG8 ENCLOSURE



(18) COLOR CODED SNAP-BUTTON POLES

(1) SIGPRO PREMIUM IMPACT SCREEN

(1) BLACK NYLON SURROUND

(4) FOAM PADDING STRIPS

(2) L-SHAPED CONNECTORS

(6) 3-WAY CONNECTORS

(2) SIDE BARRIER NETS


(70) BALL BUNGEEES

(2) SANDBAGS



OVERVIEW

SIG8 ENCLOSURE



The SIG8 was designed to fit within compact spaces, unlike other enclosure systems that require more width or height. Constructed of premium materials, your SIG8 golf simulator screen displays in HD quality and is built tough to withstand golf ball strikes up to 250 MPH.

In independent, head-to-head testing conducted by the team at MyGolfSpy, with its mission to inform and protect the golf consumer with unbiased data-driven



TRUTH DIGEST

MYGOLFSPY

methods, the SIGPRO™ Premium Golf Simulator Impact Screen outperformed what has been the industry's most popular impact screen on the market. The results proved the durability of the new SIGPRO™ Premium screen is superior to the competition, while also delivering reduced sound and bounce back.



FRAME ASSEMBLY

1A

Lay out poles and connectors. Organize by color.



(7) PURPLE poles with a single stripe on one end and double stripes on the opposite end.



(7) BLUE poles with single stripes on both ends.



FRAME ASSEMBLY

1B

(4) GREEN poles with single stripes on both ends.



TIP: In the following steps, you will connect the GREEN single stripe end to the connector pieces. You will connect the BLUE single stripe ends to the PURPLE double stripe ends.






FRAME ASSEMBLY

2


Assemble the back lower poles first. Attach a BLUE pole to a PURPLE pole. After, attach a 3-way connector to each end.



REMEMBER: Connect the double striped end of the PURPLE pole to the single striped end of the BLUE pole. And the 3-way connectors will attach to the single striped end of each pole.

3

Assemble the entire lower section by attaching (2) GREEN poles to the 3-way connectors, and then attach the (2) L-shaped connectors to the ends of the (2) GREEN poles.







FRAME ASSEMBLY

4

Connect (4) BLUE poles to the corner connectors that will act as bottom uprights for the structure



TIP: At this point in the assembly, make sure button snaps are fully engaged in each fitting. Also, this would be a good time to place the structure near its final location due to the added weight of the screen and surround in future steps.



FRAME ASSEMBLY

5

Connect (4) PURPLE poles to the BLUE uprights to complete the vertical assembly. Next, attach the (4) remaining 3-way connectors to the open ends of the PURPLE poles.





FRAME ASSEMBLY

6

Start with the back section and attach (1) PURPLE pole to the back-right 3-way connector. After, attach (1) BLUE pole to the PURPLE pole and then attach that BLUE pole to the back-left 3-way connector. Repeat these same steps for the front facing upper section.






FRAME ASSEMBLY

7

To complete the frame structure, attach the (2) remaining GREEN poles to the open 3-way connectors at the top.





ENCLOSURE ASSEMBLY



In this section, you will attach the black surround to the frame, along with the impact screen. You will need a ladder and it is recommended to have an additional person to assist with the following steps.

Unfold the black surround and position it to the outside of the frame.



1) Make sure that the velcro strips of the surround will be facing the inside of the frame.

2) Make sure the grommet holes of the surround are positioned along the back of the frame.





ENCLOSURE ASSEMBLY

B

Unfurl the black surround and bring it over the top of the GREEN pole (with the assistance of another person), and bring the surround across the structure so that it crosses atop the opposite GREEN pole and then down the opposite side of the frame.







ENCLOSURE ASSEMBLY



TIP: Start by connecting the bottom flaps of the black surround by sliding the inside piece under the bottom pole and then folding it up to secure it with the velcro strip.



Now, with the black surround atop the frame, you can attach it to the frame by pressing the velcro flaps around the poles. Once securely fastened to the frame locate all grommet holes at the back of the structure and secure with the bungee balls in each hole. This will secure the surround before attaching the impact screen.





ENCLOSURE ASSEMBLY



TIP: Before handling the impact screen, wash your hands thoroughly to avoid blemishes or stains on the white material. And make sure the floor is clean too.



Begin by using (4) bungee balls to attach the screen to the four corners. The bungee cord should be threaded through the grommet holes in the screen, then wrapped around the pole. Make sure the bungee ball is positioned outside of the enclosure. Repeat the bungee ball attachment through every grommet hole of the impact screen.

** Some, not all, grommet holes in the screen will match up with grommet holes in the surround.*





ENCLOSURE ASSEMBLY

E

The (4) foam pads can now be added to the enclosure. There are (2) long pads that will be attached to the velcro along the top and bottom of the screen, and (2) shorter pads that will attach to the two sides of the screen.





ENCLOSURE ASSEMBLY

F

To complete the enclosure and to protect walls, windows, and others from errant golf shots, add the side barrier netting to the sides of the enclosure. Simply attach the velcro side of the net along the front poles and black surround velcro strip.



Start at the bottom with the velcro and run it up the pole as high as possible. Once attached, the net can be extended outward and connect to the provided sandbag. Fill the sandbag with the appropriate amount of sand that will then keep the side barrier netting extended and taught.

SIG8

ENCLOSURE

ENJOY!

You have now assembled your own indoor golf enclosure and will have, what we hope, are many years ahead of you to enjoy playing the game we all love with your family and friends.

We stand by our products, so if you are not 100% satisfied, please contact our team so that we can try and make it right. And we're available to help with any questions that you might have about your new SIG8 enclosure. **THANK YOU AGAIN.**



The
INDOOR
GOLF *Shop*TM

CONTACT US

972-848-7491

support@shopindoorgolf.com

LOVE THE GAME ... INSIDE & OUT