


CORE® 2 ROOM INSTANT SHOWER/UTILITY SHELTER

Model No. 40058


Two people can easily setup this instant shelter in 60 seconds or less.

Contents & Repair Parts:




1 Prepare for Setup

- Select a level site clear of rocks, branches, and other hard or sharp objects, to set up your shelter.
- Remove all contents from bag.
- Unfold (4) leg poles and spread out shelter



2 Lift Shelter Steel Poles

- Grab roof poles and pull straight out to create shelter's cabin shape (leg poles will angle at joints to partially stand up).
- Lift up to lock short front & back mid roof poles.




3 Extend Leg Poles

- Extend each of the (4) leg poles until the locking buttons "click," and lock the poles into place.
- You can now easily move your shelter to its final position before installing the rainfly and securing with stakes and guylines.



4 Install Rainfly

- Drape rainfly over tent, placing "Core" logo over the side of the tent.
- Snap plastic clip attached to strap located at corner of rainfly onto leg pole between top of pole section and green button. Repeat for remaining leg poles.
- Tighten straps on rainfly to secure.
- Attach (1) hook-and-loop tab on the underside of the rainfly to each pole.



To Secure Shelter:

Stake Shelter


- Locate webbing loops sewn into the corners at the base of your shelter.
- Slide stake through webbing loop at each location; then gently extend out before securing. (Detail 1)

NOTE: Floor of shelter should be taut when staked properly.

To Secure Shelter: (continued)

Secure Guylines

- Locate guylines attached to the front and back corners of rainfly and unroll.
 - Slide stake through loop at each location, extend out and drive in to secure. (Detail 2)
- NOTE:** Four corner guylines should extend out at a 45° angle from shelter.
- Tighten guylines as needed by adjusting the slider up the cord.



Usage Instructions:

The door on the shelter allows access to the changing room. Enter the shower room by unzipping the room divider. The shower room has mesh panels around the perimeter of the floor for drainage.

To Hang Shower Bag

NOTE: Read and follow filling & usage instructions printed on the shower bag.

- Place handle on shower bag onto metal clip located along the top of the shower room.
- Gently pull down on handle to secure. (Fig. 1)

Towel Rod

NOTE: Hanging loops for towel rods are placed in 2 locations on two sides of the shelter. There are web straps with plastic clips outside the changing room and outside of the shower room.

- Place towel rod on plastic clips attached to the web straps on inside panel of the changing room or the outside panel of the shelter. (Fig. 2)



Fig. 1




Fig. 2

(continued on other side)

TAKE DOWN INSTRUCTIONS:

NOTE: Allow the shelter to dry thoroughly, remove all personal items and hanging rod before taking down the shelter.

- Remove all stakes from shelter and guylines. Store in stake bag.
- Unhook plastic rainfly clips from leg poles.
- Unfasten hook-and-loop tabs on underside of the rainfly from poles.
- Detach the rainfly, and set aside.
- Push the locking buttons and retract the (4) leg poles to closed position.
- Push down on the arm joints so the shelter lays flat.
- Fold the (4) poles in half at the arm joints, so they meet in the center.
- Gather folded shelter poles and fabric into the center to form a pod.
- Lay pod down and roll shelter to remove excess air.
- Store in carry bag with rainfly and bag of stakes.

FREQUENTLY ASKED QUESTIONS:

- **Are replacement parts available?** Yes, just call Customer Service at 888-775-5628 for replacement parts. All parts can be replaced.
- **The center of the shelter won't stand up.** You may have a broken corner joint. Check all four of the joints (under the fabric sleeves) and call Customer Service if you need a replacement.
- **The poles are not staying extended.** Check that all four green locking buttons are popped out. Extend pole farther if button is not locked. It will "click" into place.
- **How do I get everything back in the bag?** The trick is to take your time and remove all the air. Use the weight of the poles to roll the shelter on the ground and force air out. The shelter components fit in the bag, it's the air that doesn't.
- **How to clean the shelter?** Clean the shelter with a soft sponge, a mild soap and tepid water. Be sure to scrub gently and remove all soap. Let dry in sunlight, which also naturally cleans the shelter.
- **Can the shelter be used in the rain?** Absolutely. The shelter and rainfly have a waterproof treatment, and the seams have been sealed with waterproof tape at the factory.
- **How many seasons is this shelter?** This is a 2-3 season shelter, not recommended for use in severe weather conditions.
- **What are the dimensions of the shelter?** The shelter is 7' x 3.5' x 84" 213 cm x 106 cm x 213 cm.

WARNINGS & CAUTIONS:

⚠ WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS SHELTER FABRIC

This shelter is made of flame-resistant fabric which meets CPAI-84 specifications. **IT IS NOT FIRE-PROOF.** The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the product fabric may render the flame-resistant properties ineffective.

DO NOT use fuel burning devices inside or near shelter materials.

DO NOT permit children to light matches, operate burning appliances, or handle any flame sources in or near the shelter.

- Do not smoke, use matches, candles or open flames of any kind in or near the shelter.
- Do not refuel lanterns, stoves or heaters inside shelter.
- Do not cook inside shelter.
- Do not store flammable liquids inside shelter.

⚠ WARNING: Keep clear of overhead power lines.

- Do not set up your shelter under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- For best results in windy conditions, position narrow end of shelter into the wind.
- Secure with all stakes and guylines provided to prevent property damage or personal injury.
- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside of your shelter. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside the shelter. It is NOT LEAKAGE through the shelter fabric. It can be minimized by removing wet clothing from your shelter and by providing good ventilation through the shelter.
- Never store shelter, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes inside your shelter. Use a separate storage bag.
- **STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE SHELTER TO REMOVE STAKE.**
- Do not leave your shelter set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.



DO NOT SPRAY!

IMPORTANT:

THE ORIGINAL FIRE RETARDENT AND WATER REPELLENT PROTECTIVE COATINGS MAY BE COMPROMISED IF SPRAYS OR OTHER CHEMICAL TREATMENTS ARE USED ON THE SHELTER. FABRIC HAS BEEN FACTORY TREATED. IT IS HIGHLY WATER-REPELLANT; HOWEVER, IT IS NOT WATER-PROOF. ALL SHELTERS CAN EXPERIENCE SEAM LEAKAGE DURING WET WEATHER. IF YOU WANT ADDITIONAL MOISTURE PROTECTION, TRY A SEAM SEALING COMPOUND ONLY; STRICTLY FOLLOW THE MANUFACTURER'S DIRECTIONS. IT IS RECOMMENDED THAT YOU SEAL THE SHELTER DURING THE INITIAL SETUP AS WELL AS PRIOR TO EACH CAMPING SEASON. SEAM SEALER COMPOUNDS CAN BE PURCHASED AT YOUR LOCAL CAMPING PRODUCTS OUTLET. FOR MISSING PARTS CALL 1-888-775-5628.

PLEASE DO NOT RETURN THIS PRODUCT TO THE RETAIL STORE.

1-YEAR LIMITED WARRANTY:

CORE® Equipment and Elevate LLC warrants for a period of 1 (one) year from the original date of purchase, this product against any defects in materials or workmanship. At its discretion, CORE® Equipment may provide replacement parts to original purchaser. Original receipt or proof of purchase as well as proof of defect in the form of a photograph or video is required. CORE® Equipment will not be responsible for shipping costs incurred outside the continental USA. Warranty is valid for the original purchaser one year from the date of purchase and is not transferable.

This Warranty does not cover any product purchased through unauthorized dealers/distributors and/or unauthorized resellers on online auction websites. CORE uses approved and authorized distributors to furnish quality products, and CORE provides warranty coverage only on products purchased from those distributors. If the product was purchased from an unauthorized reseller, this warranty does not apply. Unauthorized resellers may sell products that are used, defective, counterfeit, or which may not be designed for use in that specific country. To determine whether the seller of a CORE® Equipment product is one that has been approved and authorized by Elevate LLC owner of the CORE® Equipment brand, please contact help@coreequipment.com or call customer service at 1-888-775-5628.

This 1-Year Limited Warranty does NOT cover normal wear and tear, abuse or misuse of this product including damage from inclement weather conditions, such as wind, rain, or hail. In case of inclement weather remove all valuables and persons and seek appropriate shelter. Under no circumstances will CORE® Equipment or Elevate LLC be liable or responsible for any incidental or consequential damages. This product is designed and intended for Recreational use only. Prolonged exposure to UV rays will cause any fabric to fade and deteriorate and is NOT covered by this 1-Year Limited Warranty. All replacement products or parts will assume the remaining warranty of the original product. This warranty gives you specific legal rights. You may also have other rights which vary from state to state. To Obtain Warranty Service: Call Toll Free 1-888-775-5628 for warranty service, repair parts, or product questions. Monday - Friday, 8:00 a.m. - 5:00 p.m. Central Time.

Elevate LLC
Overland Park, KS 66221

Made in Bangladesh • Printed in Bangladesh

Now 03/28/18