



Rowan Engineering

Single Shot Loader .177 and .22 cal. FX Streamline

Thank you for your purchase. Please read these fitting instructions before using the loader.

Your kit should contain –

1 off SSL

1 off 1.5mm short allen key

Safety first.

Observe safe practices when handling your rifle and follow the manufacturer's safety instructions when doing so.

Take extra care when working on your rifle.

Ensure that the rifle un-cocked and the safety catch is set to safe (if fitted) and is absolutely not loaded with pellets.

1. Cock the rifle and slide the loader on to the action from the right side of the rifle. This is done in a similar manner as fitting the multi-shot magazine.

2. Open the loader by pressing down the loader side lever.

Close the loader by flipping the arm.

3. A M3 grub screw located in the side wall of the loader. This can be optionally very gently tightened to locate the loader semi-permanently in position. Don't forget to loosen this when removing the loader from the rifle.

Access the grub screw from the central slot in the loader body.



4. The loader is now ready for use. (A grub screw on top of the arm can adjust the amount of grip on the pellet).