


Dr.pen M8

USER MANUAL

PLEASE READ THE MANUAL BEFORE USE








Wireless Model: Dr pen M8-W

The instrument used with both built-in battery or AC power

Wired Model: Dr pen M8-C

The instrument used with AC power only

- 1.Plug in DC adaptor to the jack
- 2.Plug in DC adaptor to AC outlet
- 3.To charge the battery:Plug the adapter into an outlet and connect it to the power interface





Preparation

- 1. Take out needle cartridge in the sterilized packaging
- 2. Fitting round slot 1 into 2 of machine, push needle cartridge horizontally up to the end.
- Lock the needle cartridge by turning it to the counterclockwise
- 4.Turn the needle cartridge clockwise and then push out horizontally if you want to remove it.



5.Start the Dr.pen M8

Press the power button for 2-3 seconds to start or shut down the device

Attention

In order to protect the instrument well, do not invert the instrument to prevent the liquid backflow



Adjustment of needle length

Adjust the depth of needle by turning the scale adjustment ring

Turn it clockwise,needle depth will be shorter Turn it counterclockwise.needle depth will be longer



Speed Display














6 Speeds Adjustment

The pen starts from low to high speed The speed changes once each time you press the button



Needle cartridge introduction





Product name:

Auto-stamp Motorized Meso Machine

Model name: Dr pen M8

Adapter: 5V-1000mA

Package Weight: 312g
Package Size: 169*123*56mm

Packing List

Item	Quantity		
Hand Piece	1 pc		
Adapter	1 pc		
Manual	1 pc		
Power Cable	1 pc		
Needle Cartridge	2 pcs		



Precaution

\Diamond	Please be sure to read instructions before use and follow as described.
<u> </u>	Do not apply if to the man as follow: 1 Who has such disease or bloody disease over 38 °C 2. Who has allergy and hemopholy disease over 38 °C 2. Who has allergy and hemopholy disease 3. Who has high internal heat 6. Who thas high internal heat 6. Who to takes medicines 7. Who is under 12 years of
0	Do not use it on the power other than AC 220V. It may cause fires or malfunction
0	Do not use it near the place with high temperature, dust or humidity (Near the humidifier).It may cause malfunction.
0	Do not repair, disassemble or alter the controller and the body. It may cause malfunction.
0	Do not touch the device or detach the power cords with wet hands. It may cause electric shock.
0	Do not use the stripped cord or propped cord. It may cause fires(Be sure to replace it with another).
0	Do not use the propped cord which has crack or scares. It may cause scares on the skin.
0	When you don't use it for a long time, unplug it from the outlet.
0	Be sure to have an inspection for test. If any troubles are found, get it repaired.
0	No one other than the operator can touch it. It may cause accidents or malfunction.

\sim	Alternating current	SN	Serial No
	Direct current	EC REP	EU Representative
	Class I equipment	Œ	CE mark
<u> </u>	Attention, consult accompanying documents	mil.	Manufacturer
M	Date of manufacture	F	Floating applied part



The warranty period of Dr pen M8 is 6 months. We offer repair to our products from the day they are purchased. If any of our products has damages or natural trouble. We offer repair or replacements

General maintenance

Make sure to inspect the device and adapter before use

Keep it with its power off. Wipe its surface out with a dry cloth

Keep it away from direct sunlight or high temperature and humidity

Do not leave the measurement, repair or alter of the device to non-professional staff

When you use the device which has not been used for a long time, make sure to check if it works properly with safety

Dr. pen M8

USER MANUAL