

CARE AND SAFETY DATASHEET

| Care & Safety | |
|--|------|
| Washable with hot water? | Yes |
| Durable | Yes |
| Reusable | Yes |
| Dishwasher safe? | No |
| Food safe? | Yes |
| Safe for children above 3 years old | Yes* |
| Safe for children under 3 years old | No |
| Storage and Handling: Keep cookie cutters in a dry environment. Stow away from the heat, direct sunlight or lightning units. Do not heat, do not put in the oven or in the microwave oven. Do not wash in dishwasher (hand-wash in warm water only). | |

WARNING
Choking Hazard

*Any cookie cutter with sizes less than 3"x 3" is considered choking hazard and should not be used or played by age 5 or less without adult supervision.