

# Cranky Croc Double Inflatable Swag

INFSWAG-DBL



## General safety instructions:

\*Failure to obey these instructions will cause death or serious injury.

### Hazard of carbon monoxide poisoning

Never use barbecues, gas heaters or any other fuel-burning appliances inside the tent/swag. The burning process produces carbon monoxide which accumulates inside the tent/swag as there is no flue. Ingestion of carbon monoxide can cause death.

### Fire hazard

Ensure you have knowledge of fire restrictions and warnings around your camp site.

Do not cook inside the tent/swag or use open flames. Leave the tent/swag immediately in case of fire.

### Beware of suffocation

Ensure ventilation openings are open and clear all the time to avoid suffocation. Dispose of or store appropriately any packaging as they may pose a suffocation or choking hazard.

### Risk of injury

This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety.

Do not allow children to play around the tent/swag and ensure that suitable protective footwear is worn. Guy lines are a trip hazard and pegs can be sharp.

## Intended use :

This tent/swag is suitable for:

- Light to moderate weather
- Camping/touring

This tent is not suitable for:

- Very strong winds or snowfall
- Seasonal pitch, long term or commercial use

This product is only suitable for the intended purpose and application in accordance with these instructions. Poor or incorrect installation and/or improper operating or maintenance will result in unsatisfactory performance and a possible failure.

The manufacturer accepts no liability for any injury or damage to the product resulting from:

- Incorrect assembly, incorrect maintenance, or use of spare parts other than original spare parts provided by the manufacturer, alterations to the product without express permission from the manufacturer or for purposes other than those described in this manual.

## PLEASE NOTE BEFORE SET UP:

CAUTION! Risk of injury and material damage

- Do not use any type of compressor designed to inflate car tires. • Only inflate the air poles with the supplied hand pump to maximum 6-7 psi/0.41/ 0.48 bar).
- Do not open or close the zippers with force.
- Never open the zipper on the protective sleeve while an air pole is inflated. This will result in the air pole bursting.
- Do not use excessive force when dismantling as you may damage the material.

The product is manufactured with polycotton canvas requiring preparation before use to maximize its weatherproofing. Before first use, fully set up the product outside and hose the outside of the product to become thoroughly wet. This process is known as seasoning. The seasoning process tightens the fabric, allowing the cotton swell and fill the holes made by the sewing needle during the manufacturing process. Allow the product to dry thoroughly and repeat if possible. Ensure product is completely dry before packing away.

## SET UP:

1. Unpack swag and lay flat on even clear ground. (to protect from dirt and damage, lay down a ground sheet or swag mat underneath.)
2. Locate the dual inflation cap at the base of the swag (logo end) (see Figure 1)
3. Ensure the large inner cap is screwed into the valve with the small inner cap screwed off (as pictured Figure 1).
4. Attach appropriate valve fitting to the pump and insert into the inflation point.
5. Standing the pump upright and placing both feet on the footplate of the pump, pump continuously until swag is upright. DO NOT over inflate.

6. Remove the pump and screw valve cap back on.
7. Lay the mattress on flat ground and locate the dual valve end of the mattress (one valve on each corner)
8. Ensure one valve is closed while you attach pump directly to the open valve.
9. Standing on the upright pump at the footplate, pump continuously until mattress is firm. DO NOT overinflate.
10. Ensure caps are plugged in tightly after inflation of mattress.
11. To top up air, locate valve at other end of the mattress. Open the cap and using the pressure of your feet or hands on either side of the valve, pump further air in. (pic 3)
12. Lay mattress inside the assembled swag.
13. Peg out the corners, driving the pegs in at 45 degree angle away from the base of the swag.
14. Peg the guy-ropes in-line with the seam that it comes out from. Retighten as required.
15. Set up awning if desired using the poles and guy-ropes provided.



Figure 1



Figure 2



Figure 3

#### **PACK UP:**

1. Remove any dirt from inside and outside.
2. Close all windows and zip up flaps.
3. Open the valve on mattress.
4. Zip up all doors and openings.
5. If installed, remove the awning poles.
6. Remove all ropes and pegs
7. Remove all pegs between the corner pegs.
8. Open the deflation valve located at base on logo end (dual inflation cap- see Figure 2)
9. Wait until most of the air has been expelled.
10. Remove the four corner pegs.
11. Fold/roll the tent towards the valves to expel more air.
12. When deflated, roll the swag to fit into the carry bag.
13. Ensure that all parts are clean before packing them into the carry bag.
14. If the tent is wet or damp when packing away, dry fully as soon as possible to avoid mould.

