


Space Saver Cot Top Changer

Instructions

Version: R1-0-1



IMPORTANT
KEEP FOR FUTURE REFERENCE



Thank you for choosing Obaby. This cot top changer conforms to BS EN 12221:2008+A1:2013. To ensure that your cot top changer is used in accordance with these instructions, please read them fully.

Your child's safety may be affected if you do not follow these instructions.

WARNING: Do not leave the child unattended.


WARNING: Assembly should be carried out by a competent adult only.



- The cot top changer must be used on a level and stable surface.
- Never move the cot top changer with the child on it.
- Be aware of the risk of open fire and other sources of heat, such as electric bar fires, gas fires, etc. in the near vicinity of the cot top changer.
- Do not use the cot top changer if any part is broken or missing. Use only spare parts approved by the manufacturer.
- We recommend you use a changing mat with maximum dimension of 70cm x 46cm, placing the mat evenly inside the cot top changer.
- The changing surface is designed for use from birth until 12 months, max weight 11kg.
- All assembly fittings should be tightened properly and care should be taken to ensure that no screws are loose, as a child could trap parts of the body, or clothing (e.g. ribbons, drawstrings, necklaces) this could lead to strangulation.
- Regularly check that all fittings and components of the cot top changer are fully tightened and in working order.
- Wood is a natural material, the colour will darken with age.
- During assembly children should be kept away from the product due to possible risk of injury.

ROUTINE CARE & MAINTENANCE


- For cleaning, use only a mild detergent and warm water.
- DO NOT USE BLEACH.
- DO NOT USE any abrasive substances.
- Take care when handling or moving furniture, careless handling can damage wooden furniture.

Due to constant updating and improvements, some components may occasionally differ slightly from the images shown in these instructions. We reserve the rights to change the specifications of any products without prior notice. If you need any assistance please contact your Obaby retailer from whom you purchased your product, who will take appropriate action.




P1	P2	P3
		
35mm		
x 6	x 6	x 1



Step 1




Step 2



Step 3



Step 4



Secure in place using the hook and loop tape.

