WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to company within 15 days from the date of purchased. our guarantee the provision of free services of KRISONS product within the warranty period from its date of purchased from Authorised dealer.

This period and conditions of our services are as follows :

- 1. The warranty covers services by our KRISONS Authorised service center. The warranty card together with invoice must be presented when servicing is required. The warranty card is irreptaceable in the event of lose
- 2. Repair services will be provided for defects arising from normal usage for the following period commencing from the date of purchase from KRISONS Services center. (parts would be replaces when necessary)
 - A. Electrical parts 6 months
 - B. Technical services free 6 months
- Under the following circumstance, service and parts will be 3. chargeable even within warranty period.
 - A. Failure to present the warranty card and invoice when service is required Full particulars not clearly shown or alterations made against information. For E.g. Alteration of date of purchases. serial number altered of removed
 - B. This unit being tempered with, altered in any way by any unathorised technicians or which has been subjected to misuse, negligence or accident. This warranty does not cover damage occurning in transit by or from the customer
 - The defect is caused by the attack of household pests, C fire lighting, natural disasters pollution. abnormal voltage or the usage of generator.

Specifications

Beatz / Buddy

Output Power :

Front Speakers : 25w x 1 (THD+N=10%, 1KHz) **Speakers Unit** : Frontspeakers : 6"/3 Ω x1 Power: 3.7 V / 2400 mAh **Compatible :** Smartphone's and tables supporting Bluetooth (A2DP) Protocol. Frequency Response :

Front Speakers: 840 Hz - 10 KH

Separation :> 35 db s/nRatio: 65db

Contains Package

- 1. Main Unit 1Pc.
- RemotecControl-1Pc. 2.
- Wired Mic-1Pc 3.
- 4. Operating Manual 1Pc.
- Chargeable Cable 1Pc. 5.
- 6. Warranty Card.

Marketing and Manufacturing by :

ZYTEL ENTERPRISE PRIVATE LIMITED

Address: A-137, 2nd Floor, Okhla Industrial Area, Phase-2, New Delhi-110020, INDIA

E-mail : service@krisons.com Website : www.krisons.com

RISON

Customer Helpline No.: +91 9910016757, 8287124581 (Timing: 10.30 AM-6.00PM (Monday - Saturday)

CAUTION :

- Do not place the system in the high-temp and humid environment prevent it from raining or rough handling and strong shock.
- In order to avoid electric shock and other accidents do not open the set for repair without any professional guidance.
- In case fragments or other liqids is accidentally sprinkled inside the cabinet please switch off power immediately in case of repair please visit to the professional maintenance for help.
- Switch off the power and take off the charger from the power socket when the system is not on work.
- Keep it safe from water drops or splashing water. and no liquids container should be a allowed to be put on its top side.
- Keep the cabinet vent away from the wall by least 20 mm the vent should not be blocked from air. Do not keep it close to the fire.






- 1. Mic Socket
- 2. ON / Off Switch.
- 3. 5V Charging socket. You can charge with any charger whose capacity is Minimum 1 Amp or More
- 4. Charging indicator. (During charging this will indicate in Red) 5. Display.
- 6. Rotary Volume control.
- 7. Mode: Change the function to FM, Bluetooth, Line in/Aux & USB
- 8. Previous: << (USB): Previous Song will be change (FM): Previous Preset program will change (Bluetooth): Previous Song will be change
- 9. Play/Pause : (USB,FM & Bluetooth): You can play & pause the songs.
- FM, if you long press in FM, it will Auto tune the FM channel and memorized Also sequentially
- 10. Next : >> (USB): Next Song will be change (FM): Next Preset program will change (Bluetooth): Next Song will be change
- 11. Aux Socket : (Any other source of external stereo audio signal can apply from TV, Mobile Laptop, And Computer by connecting the aux wire)
- 12. USB/ Pen Drive Port. (You can play Audio songs in MP3 Format)
- 13. Micro SD Card Socket: (You can play Audio songs in MP3 Format

- **Remote Function of Beatz / Buddy** 1. Power: White press off the product
 - comes in standby mode display goes off no function will work.
 - Mode: Short press Change the function 2. to FM, Bluetooth, Line in/Aux & USB. Equalizer Function: Select Audio Effect 3. through Pre equalized (i.e.) Jazz, Rock,
 - Pop, Classic, Country Normal. Note: (This function will work only during USB Play & Bluetooth.)4. Mute: While press you can mute the
 - sound. 5. Cursor Key: i. Volume + / - Volume will increase or
 - decrease in all mode ii. Next ►► (USB): Next Song will be change
 - (FM): Next Preset program will change (Bluetooth): Next Song will be change
 - iii. Previous **44** (USB): Previous Song will be change (FM): Previous Preset program will
 - change (Bluetooth): Previous Song will be

change

- iv. Play/Pause: (USB,FM & Bluetooth): You can play & pause the songs. FM, if you long press in FM, it will Auto tune the FM channel and memorized also sequentially
- 6. REPEAT: You can choose option of song play All songs or Single song while USB play
- 7. Numeric Buttons: (0-9) you can select song track while Playing USB drive and change FM Programme/Stations directly.
- 8. Echo Level + / (you can adjust the level of echo effect during using mic)
- 9. Mic Level + / (you can adjust the level of mic according to you choice)



WARRANTY CARD

WARRANTY REGISTRATION CERTIFICATE

Mr/Mrs/Ms First Name :
Last Name :
Address
Contact No.
Model No
Serial No.
Date of Purchased :
Invoice No.
Retail outlet/Website name Where Purchased :
Purchased Order No./Date