



Features & Benefits

Jade™ | 20

Top Features

- Large sewing space – 200mm
- Uniquely Designed Accessory Compartment
- Start/Stop function
- Sewing Guide
- More than 80 beautiful 7mm wide stitches
- 7 HUSQVARNA VIKING® original snap-on presser feet included
- Large assortment of HUSQVARNA VIKING® optional accessories
- Presser foot Recommendation-Button
- Speed Control



Note: For more details about the top features, look for the framed sections.

SEWING

200mm SEWING SPACE

Sew large quilts, home dec projects and garments easily.

- Large area to the right of the needle for wonderful ease of sewing.

START/STOP FUNCTION

- Sew without the foot control for easy, consistent speed.
- Press Start/Stop to begin and to stop sewing without using the foot pedal.
- Great for sewing rows of decorative stitches, sewing on buttons, making buttonholes and winding a bobbin.
- Ideal for sewers with physical limitations.

SEWING GUIDE

- Easy to select the best stitch, stitch length, stitch width, thread tension, presser foot and presser foot pressure for the selected sewing technique and fabric.

82 BEAUTIFUL 7mm WIDE STITCHES

- Select from a wide variety of stitches for every technique and endless creative opportunities. You will always have the perfect stitch for every project.

LARGE ASSORTMENT OF OPTIONAL ACCESSORIES

- Many optional accessories for every sewing need and creative possibility. For all different types of sewing, quilting, home dec and more.

PRESSER FOOT RECOMMENDATION-BUTTON

- Shows the presser foot recommendation for the selected stitch on the LED display.

ONE-STEP BUTTONHOLES

- Buttonholes are quickly and easily sewn in a simple one-step process. Both columns are sewn in the same direction to lay smoothly and prevent distortion.
- Choose from five different styles for various sewing applications.

NEEDLE STOP UP/DOWN

- For easy pivoting, appliqué and more.

DROP FEED TEETH

- Easy to lower feed teeth at the back of the free arm for button sewing and free motion quilting.

FREE MOTION WITH ANY STITCH

- For easy quilting and beautiful free motion embroidery using any stitch you choose.

MIRROR IMAGE SIDE-TO-SIDE

- Flip stitches side-to-side for unlimited creative sewing.

29 NEEDLE POSITIONS

- Sews a straight stitch in 29 different needle positions for perfect topstitching, edge stitching, under stitching, stitching-in-the-ditch or quilting. Adjust and mirror the stitch length and width.

ADJUSTABLE PRESSER FOOT PRESSURE

- Sew any fabric weight and type with perfect results.

MACHINE

UNIQUELY DESIGNED ACCESSORY COMPARTMENT

- Modern, convenient and easily accessible storage for all the included accessories.
- The sleek modern compartment will look stylish when the sewing machine is not in use.

7 HUSQVARNA VIKING ORIGINAL SNAP-ON ACCESSORY FEET INCLUDED.

- A wide selection of easy snap-on presser feet are included with the HUSQVARNA VIKING® JADE™ 20 machine, including the One-Step Buttonhole foot.

SPEED CONTROL

- Easily adjust the sewing speed for greater control.

BUILT-IN NEEDLE THREADER

- Makes threading fast, easy and hassle free.

LED DISPLAY

- Chosen stitch is shown by number in the LED display.

BOBBIN WINDS FROM THE NEEDLE

- No need to unthread the machine when winding the bobbin.

LED LIGHTS

Reduces shadows while sewing.

- LED lights illuminate the needle area and sewing surface to make sewing easy and reduce eye strain.