

## Replacement Parts List

Item	Part No.	Description
1	RP-UG107	Gas Train Assembly <b>for Natural Gas</b>
	RP-UG108	Gas Train Assembly <b>for Propane</b>
2	RP-CE201	Ignition Module
	RP-CE202	Wire Harness w/ 5 pin PLUG to Ignition Module
3	RP-CE382	Blower Motor Assembly w/ 0.20A PSC 2SPD Motor
4	RP-CE058	Transformer, 115V to 24VAC, 40VA
5	RP-CE021	<b>For ETSV 40:</b> Air Switch w/ Bracket, 0.55" w.c.
	RP-CE028	<b>For ETSV 60:</b> Air Switch w/ Bracket, 0.78" w.c.
	RP-CE160	<b>For ETSV 80:</b> Air Switch w/ Bracket, 0.44" w.c.
6	RP-UG007	Burner Cup
	RP-CE002	Electrode for Sparking
	RP-CE003	Electrode for Flame Sense
	RP-CE006	Wire, Ignition
	RP-CE036	Wire, Flame Sense
7	RP-CE057	Operation Light, Amber, 28VAC
8	US225ALC	Grill aluminum (For other finishes contact manufacturer)
9	ESCP1R	Service Door Aluminum (For other finishes contact manufacturer)
10	US234AL	Cowling Aluminum (For other finishes contact manufacturer)
11	RP-CE173	Blower Motor Relay
-	RP-CE010	Power Cord <i>(Not Shown)</i>

