

面皮外 x 1

Outside

200

R50

210

钞位 × 2

Bill slots


200

8

零钱位 × 1

Change Slot

190



面皮里×1


Inside

R2

105

140

40



零钱位×1

Change Pouch

190

140

卡位01×1

Card Slot

40

60

34

X6

