



PORTABLE FOLDABLE SOLAR PANEL INSTRUCTIONS

PV60CASE & PV130CASE

Product Inspection

1. Confirm there is no visible damage to the product.
2. Contents include panel and pre-wired charge controller cables.

Installation

1. The panel includes a prewired positive and negative cable that connects to a solar charge controller providing a charge to an external battery.

Brown wire = positive (+)

Blue wire = negative (-)



2. The wires connect to a charge controller via the spade lug on the end. Some charge controllers may connect via bare wire. If this is the case, simply cut off the spade lugs and slide bare wire into the controller.
3. Ensure the cables are connected securely. Do NOT reverse the polarity. This will damage the panel and void the warranty.
4. Position the solar panel so the panel is receiving optimal sunlight.
5. Connecting the solar panel to charge controller:
 - Make sure the charge controller is connected to the battery FIRST, then connect the panel to the charge controller.
6. Disconnecting the solar panel to charge controller:
 - Make sure to disconnect the solar panel FIRST, then disconnect solar charge controller from battery.



CAUTION

Make certain that the brown and blue solar panel cables never touch/cross. The solar panel provides electricity as soon as the panel receives sunlight. The wires are hot and can cause a short, which will damage the panel. Do NOT reverse the polarity! This will damage the charge controller and the panel. This will void the warranty.

Example of the portable, foldable solar panel connected to a charge controller and battery:

