



PRODUCT GUIDE

Detailed Product Information



Fanback Series and Tables



#360 Fan Back Chair
32" deep x 32" wide x 40" high
Seat: 20" deep x 21" wide x 15" high



#365 Fan Back Rocker
32" deep x 32" wide x 44" high
Seat: 20" deep x 21" wide x 18" high



#202 Fan Back Settee
36" deep x 68" wide x 40" high
Seat: 20" deep x 21" wide x 18" high



#701 Ottoman
25" deep x 23" wide x 15" high



#700 Folding Chair
36" deep x 32" wide x 41" high
Seat: 18.5" deep x 23" wide x 15" high



#69 Conversation Table
38" round x 20" high



#76 Round Side Table
22" round x 20" high



Cup Holder
7" wide x 7" deep

Glider Series



#119 Fan Back Swivel Glider
28" deep x 28" wide x 45" high
Seat: 20" deep x 21" wide x 18" high



#114 Fan Back Glider
28" deep x 28" wide x 45" high
Seat: 20" deep x 21" wide x 18" high



#340 Fan Back Glider
28" deep x 51" wide x 45" high
Seat: 20" deep x 41" wide x 18" high



#970 Coffee Table
17" deep x 39" wide x 18" high



#111 Easy Glider
32" deep x 29" wide x 42" high
Seat: 20" deep x 20" wide x 18" high



#404 Easy Glider
32" deep x 53" wide x 42" high
Seat: 20" deep x 43" wide x 18" high



#110 Curve Back Glider
30" deep x 28" wide x 40" high
Seat: 18" deep x 21" wide x 18" high



#406 Curve Back Glider
30" deep x 51" wide x 40" high
Seat: 18" deep x 44" wide x 18" high



#506 Curve Back Glider
30" deep x 63" wide x 40" high
Seat: 18" deep x 56" wide x 18" high



#116 Curve Back Swivel Glider
30" deep x 28" wide x 40" high
Seat: 18" deep x 21" wide x 18" high



#400 West Chester Glider
30" deep x 51" wide x 36" high
Seat: 18" deep x 44" wide x 18" high



#500 West Chester Glider
30" deep x 63" wide x 36" high
Seat: 18" deep x 56" wide x 18" high

Swings and Lounges



#341 Fan Back Swing
32" deep x 46" wide x 32" high
Seat: 20" deep x 39" wide



#414 4' Easy Swing
32" deep x 63" wide x 32" high
Seat: 20" deep x 56" wide



Poly A-Frame
for swing available in 4', 5', 6'
76" deep x 86" wide x 76" high



#410 West Chester Swing
30" deep x 46" wide x 24" high
Seat: 18" deep x 39" wide



#510 West Chester Swing
30" deep x 63" wide x 24" high
Seat: 18" deep x 56" wide



#416 Curve Back Swing
30" deep x 46" wide x 28" high
Seat: 18" deep x 39" wide



#516 Curve Back Swing
30" deep x 63" wide x 28" high
Seat: 18" deep x 56" wide



#801 Poly Chaise Lounge
80" deep x 23" wide x 44" high
Seat: 45" deep x 23" wide x 15" high
Back is 20" high



#801 Poly Chaise Lounge
Standard without Arms:
80" deep x 23" wide x 44" high
Seat: 45" deep x 23" wide x 15" high



#365 Fan Back Rocker
32" deep x 32" wide x 44" high
Seat: 20" deep x 21" wide x 18" high

Chairs, Benches, Rockers



#920S English Garden Chair without Arms
26" deep x 23" wide x 41" high
Seat: 18" deep x 25" wide x 18" high



#920 English Garden Chair
26" deep x 25" wide x 41" high
Seat: 18" deep x 18" wide x 18" high



#940 English Garden Bench
26" deep x 46" wide x 41" high
Seat: 18" deep x 39" wide x 18" high



#420 West Chester Bench
30" deep x 51" wide x 36" high
Seat: 18" deep x 44" wide x 18" high



#520 West Chester Bench
30" deep x 63" wide x 36" high
Seat: 18" deep x 56" wide x 18" high



#300 Curve Back Chair
30" deep x 28" wide x 40" high
Seat: 18" deep x 21" wide x 18" high



#426 Curve Back Bench
30" deep x 51" wide x 40" high
Seat: 18" deep x 44" wide x 18" high



#526 Curve Back Bench
30" deep x 63" wide x 40" high
Seat: 18" deep x 56" wide x 18" high



#301 Curve Back Rocker
36" deep x 28" wide x 39" high
Seat: 18" deep x 21" wide x 17" high



#325 Easy Rocker
36" deep x 29" wide x 41" high
Seat: 20" deep x 20" wide x 18" high



#84 Poly Lumbar Rocker
32" deep x 26" wide x 44" high
Seat: 18" deep x 19" wide x 17" high



#83 Poly Hickory Rocker
32" deep x 27" wide x 40" high
Seat: 18" deep x 21" wide x 17" high

Dining Sets



#920S English Garden Chair without Arms
26" deep x 23" wide x 41" high
Seat: 18" deep x 25" wide x 18" high



#920 English Garden Chair
26" deep x 25" wide x 41" high
Seat: 18" deep x 18" wide x 18" high



#78 Bistro Chair
26" deep x 26" wide x 43" high
Seat: 19" deep x 19" wide x 18" high



#67 Bistro Table
30" diameter x 30" high



#970 Coffee Table
17" x 39" x 18" high



#71A Dining Table
43" x 43" x 30" high

ask about
custom sizes



#71B Dining Table
43" x 72" x 30" high



#71C Dining Table
43" x 96" x 30" high

— Dining Tables Also Available in Pub Height —

Balcony & Pub Sets



#79 Swivel Balcony Chair
27" deep x 26" wide x 49" high
Seat: 19" deep x 19" wide x 26" high



#77 Swivel Pub Chair
27" deep x 26" wide x 47" high
Seat: 19" deep x 19" wide x 26" high



#74 Double Tier Table
22" diameter x 27" high



#75 Balcony Chair
28" deep x 26" wide x 51" high
Seat: 19" deep x 19" wide x 25" high



#752 Balcony Settee
32" deep x 72" wide x 51" high
Seat: 19" deep x 19" wide x 25" high



#68 Pub Table
30" diameter x 39" high



#70 42" Pub Table
42" diameter x 39" High



#72 Half Round Table
22" deep x 46" wide x 39" high



#73 Barstool





#950 Planter Bench
18" deep x 18" high




#960 Planter
18" x 18" x 18" high



#350 Kennebunkport Chair
Standard in White Poly or Wood Only

17 Colorful Options



Two-Tone Color Combinations

Your choice of color combinations are available.



We Ship via.



Fanback Chairs packaged on pallets and prepared for shipping. Each skid contains 14 fanback chairs.

