



Assembly Instructions

Hickory Dining Chair with Arms



*Thank you for choosing **A&L Furniture Co.***

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us at
help@aandlfurniture.com or call us at 866-896-5747

PARTS (included)

Ⓐ Chair (1)

Ⓑ Left Arm (1)

Ⓒ Right Arm (1)



HARDWARE (included)

ⓐ 1 $\frac{3}{4}$ " Bolts (4)

ⓑ Allen Wrench (1)



TOOLS NEEDED

None

STEP 1

Fasten the arms to the chair as shown (photo 1) aligning the holes in the arms and arm braces with the ones in the chair seat and back. Insert a 1 $\frac{3}{4}$ " bolt into each hole. (See photo 2.) Tighten with the Allen wrench.




photo 1




photo 2