



Assembly Instructions

Hickory Writing Desk



*Thank you for choosing **A&L Furniture Co.***

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us at
help@aandlfurniture.com or call us at 866-896-5747

PARTS (included)

(A) Desk Top (1)

(B) Legs (4)



HARDWARE (included)

(a) 5/16" Washer (8)



(b) 5/16" Hex Nut (8)



TOOLS NEEDED

1/2" Wrench or Socket

STEP 1

Attach one leg to each corner of the desk top. (See photo 1.) Make sure the bolts in the legs are inserted properly through the corner brackets. Put a 5/16" washer on each bolt followed by a 5/16" hex nut. (See photo 2.)




photo 1




photo 2

STEP 2

Set the desk upright on the floor and test for stability. If it rocks or wobbles you may have to adjust 1 or 2 of the levelers on the bottom of the legs. (See photo 3.) You should be able to turn these with your fingers, if not you can use pliers.



photo 3