


naeo

DIFFUSING WELLNESS

FACIAL STEAMER



Please read this manual carefully and keep it in a safe place.

WARNINGS


- Water tank only allows pure water and distilled water. DO NOT fill with essential oil, or any other liquid into the water tank, to avoid any explosion.
- When steaming the face, please keep a distance of 25 cm from the steam nozzle, to avoid any risk of scalding.
- DO NOT Immerse this unit or the power cord with plug into water.
- Please use correct voltage 220 V/ 50 Hz.
- DO NOT fill with any cleanser or chemicals in water tank.
- When filling water please make sure to turn off the power and unplug the power.
- DO NOT put the power cord close to a hot surface.
- Please stop using it if the unit spills water from the steam nozzle, be careful of burns.
- DO NOT hand over this unit to the people or children who are not familiar using this product to avoid any risk of scalding.
- DO NOT use this unit if the electrical cord or outlet is damaged. If such damage occurs, DO NOT disassemble or attempt repairs, take the unit to a qualified service person for examination and repair.
- Unplug the power after using this unit and before cleaning or maintenance.
- DO NOT use this unit with wet hands. DO NOT put this unit or store it near a water sink, or water/ any other liquid, or high humidity place.
- This appliance can be used by children aged 8 or over and by persons with reduced physical, sensory or mental capacities or those lacking experience or knowledge, provided that they are properly supervised or the instructions for safe use of the appliance have been provided to them and the risks involved have been understood. Children must not play with the appliance. The appliance must not be cleaned or maintained by unsupervised children.
- To be used in an environment from 10°C to 30°C. Continuous use of the appliance may, in the long term, damage the product and shorten its life span.

- The appliance must only be used with the power supply provided.
- Unplug the appliance before any operation or handling. Empty the water tank when the appliance is not in use.
- Do not open, or handle the appliance when it is turned on.
- Keep the appliance out of the reach of children and animals.
- If water gets into the appliance, switch off/unplug the appliance immediately and leave it to dry in the open air for a minimum of 3 days before using it again.
- Clean the appliance after use to avoid build-up of grease or other residues.
- Do not use chemical products (such as acids, alkaline, etc.) or corrosive detergents to clean the appliance.
- In the event of malfunction, immediately unplug the appliance and the power cable.




The manufacturer is not responsible for any damage caused by improper use.

INSTRUCTIONS FOR USE



1. Place the unit on a flat surface, away from the edge.
2. Remove the water tank located at the back of the device.
3. Unscrew the cap and fill the tank with 160ml of pure water or distilled water. Screw the cap back on and put the water tank back in place.
- 4-5. (Optional) Remove nozzle cap. Put 1 to 2 drops of floral water on the felt pad located inside the cap. Replace the cap on the nozzle.
6. Plug the device into a power outlet and press the main button to turn it on.
7. After 30 seconds, hot steam comes out of the nozzle. Place your face 25 cm from the nozzle. Adapt the distance according to the sensitivity of your skin for a comfortable session.

BEAUTY RITUAL



1. Prep Your Skin: Remove makeup and cleanse your skin before using the facial steamer.
2. Steam Away: The hot steam will come out 30 seconds after turning on the device. Place your face about 25 cm from the nozzle and relax during your session (25 min maximum).
3. Skincare Boost: After the session, your pores are opened. Enhance the full effects of your mask or cream with a deeper skin penetration.
4. Enjoy Refreshed Skin: Use the facial steamer once or twice a week. Your skin is detoxified, cleared of impurities, soft, and hydrated!

SAFETY

The following safety rules must be observed when using this product:

1. Do not pour any liquid other than pure water or distilled water into the tank.
2. When performing a facial sauna, keep the face at least 25cm away from the steam nozzle.
3. To avoid burns, do not touch the nozzle when the unit is in operation.
4. For the first few uses, the device may give off a slight odor, allow the device to warm up a little before using it.
5. If you feel any pain or strange sensation on your skin, stop using this device immediately.
6. Use this device on a stable surface, do not shake or move it.
7. Persons sensitive to heat, the elderly and children should not use this appliance.
8. Stop using the appliance immediately if water comes out of the steam nozzle. Clean the device first before using it again.

CLEANING PROCESS

- Unplug the appliance and let it cool down for 15 minutes.
- Fill the water tank with 160 ml of pure water or distilled water, close the cap and put the tank back in place.
- Hold the device with both hands and shake gently several times.
- Take out the water tank. Drain the water and let it air dry before putting it back in place.
- Turn the device upside down and empty all the water from the device.
- Make sure there is no water left in the device and allow it to air dry.

MAINTENANCE

- Do not use abrasive sponges, abrasive cleaning agents or corrosive liquids. After each use, wipe the body of the device with a damp cloth and dry it with a dry cloth.
- Cleaning after each session: once the vaporization is finished, remove the plug, remove the water tank and turn the device over to evacuate all the remaining water. Allow the water tank to air dry before storing.
- Clean the device after each use to avoid any accumulation of residues.

TROUBLESHOOTING

Problem	Possible cause	Solution
The unit does not work.	The power button is not On.	Turn on the power button.
	The unit is not connected to a power supply.	Check that the plug is properly inserted and that the power socket is working.
No steam.	Little or no water in the water tank.	Fill up the water tank (up to 160ml).
	Water tank not well inserted.	Insert the water tank back properly.
Water splashes out of the nozzle.	There may be residues/dirt inside the device.	Clean the appliance following cleaning and maintenance instruction of the manual.

TECHNICAL CHARACTERISTICS

Model: NV8308A
Item number: BD-GD1005
Tank capacity: 160ml
Automatic safety stop: 25min
Works on mains: 220V / 50 Hz
Power: 300W

Everview Trading Ltd, 5 West Victoria Dock Road, DUNDEE, DD1 3JT, UK
Green Delta Ltd c/o SEDIS Logistics, 7 Rue des Sablières, 7522 Blandain, Belgium
Made in China



Correct disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

