

# CHELSEA CLOCK

## Quartz Battery Installation Reference Sheet

We are pleased to provide battery installation instructions for our most popular models of Chelsea quartz timepieces. If you have questions or do not see your particular model clock featured, please contact our Customer Service representatives at 866-899-2805, or via email at [customerservice@chelseaclock.com](mailto:customerservice@chelseaclock.com)


### BOARDROOM




#20979



Unscrew both brass knobs on clock back plate.



Lift off plate and remove.



Insert "AA" battery. Follow+ and - polarity. Replace back plate and fasten knobs.

### CHARTWEIGHT



#20981, #90981



Turn battery compartment cover counterclockwise, using fingernail or screwdriver.



Insert button cell battery. Follow + and - polarity. Replace cover and turn clockwise to lock.

### CONSTITUTION




#20886



Unscrew bezel on front of clock. Turn counterclockwise.



Tilt clock forward and remove dial/mechanism assembly from base.



Insert "AA" battery. Follow+ and - polarity. Return assembly to base, aligning top notch. Replace bezel, turning clockwise.


# CHELSEA CLOCK

## Quartz Battery Installation Reference Sheet


### DUXBURY



#21051



Turn base screw counterclockwise one turn. Do not remove screw completely.



Tilt clock forward and remove dial/mechanism assembly from case.




Insert "N" battery. Follow + and - polarity. Return assembly to base, aligning notch. Tighten screw, turning clockwise.


### EMBASSY



#20860



Pull open door on back of clock.



Insert "AA" battery. Follow + and - polarity. Close door.

### HARWICH



#21073



Turn base screw counterclockwise one turn. Do not remove screw completely.



Tilt clock forward and remove mechanism assembly from base.



Turn battery compartment cover counterclockwise, using fingernail or screwdriver.



Insert button cell battery. Follow + and - polarity. Return assembly to case, aligning notch. Turn screw clockwise.


### MAYFAIR



#20980



Turn knob counterclockwise and pull open back plate.



Insert "AA" battery. Follow + and - polarity. Replace back plate and turn knob clockwise to lock.

# CHELSEA CLOCK

## Quartz Battery Installation Reference Sheet


### PATRIOT CLOCKS



Turn knob counterclockwise to unlock bezel.



Open bezel completely.



Insert "AA" battery. Follow + and - polarity. Close bezel. Press down and turn knob clockwise to lock.

### RADIO ROOM CLOCK



#40101, #21065



Turn knob counterclockwise to unlock bezel.



Remove three screws on the front of the dial. Tip clock forward and remove assembly.




Insert AA battery. Follow + and - polarity. Return assembly to case. Replace screws. Close bezel. Press down and turn knob clockwise to lock.


### SQUARE ALARM




#20974, #90974



Unscrew center knob on back of clock. Turn counterclockwise.



Lift back plate and remove.



Insert "N" battery. Follow + and - polarity. Return assembly to case. Replace center knob, turning clockwise to tighten.

### PRESIDENTIAL



#20906

### CHATHAM



#20864

### SHIPSTRIKE



#27061

### DARTMOUTH



#20989

Clocks pictured above have screw bezels, similar to the Constitution. Follow instructions for opening and installing batteries.

Dartmouth has back plate similar to Mayfair. Follow instructions for opening and installing batteries.