
SAFETY PRECAUTIONS

- 1. Make sure incoming pressure does not exceed the rated pressure.
- 2. Use proper eye protection when assembling and using the hose reel.
- 3. Assemble the hose reel on a clean workbench free of debris and moisture.
- 4. Use soap and water when checking for air leaks.
- 5. Keep children away from work area.



HOSE

FROM GENERAL PUMP

OPERATOR'S MANUAL

WARNING!

Exposure of skin directly to pressurized air or fluids could result in severe bodily injury!

> Ref 300631 Rev. F 05-12

General Pump 1174 Northland Drive • Mendota Heights, MN 55120 Phone: 651.686.2199 • Fax: 800.535.1745 www.generalpump.com · email: sales@gpcompanies.com Ref 300631 Rev. F 05-12

General Pump

is a member of

The Interpump Group








ASSEMBLY AND OPERATING INSTRUCTIONS

- Connect the handle to the flange. Nuts go on handle side of flange.
 Use (4) 3/8" or 10 mm bolts when securing the hose reel to ceiling or
- wall.
- 3. Use the provided nuts, bolts and mounting bracket when securing hose reel to a cart.
- 4. Use thread sealant (not provided) on inlet threads and on outlet hose (not provided).
- 5. Attach pigtail end to high pressure pump outlet.
- 6. Attach hose reel hose to swivel on hose reel
- 7. The hose reel is ready for operation.




	Dimensions (mm)			
	A	В	С	D
DHR50100D	313.4	250.4	375.5	252.4
DHR50150D	411.5	348.4	375.5	252.4
DHR50200D	503.5	364.4	375.5	252.4

Ref 300631 Rev. F 05-12

SPECIFICATIONS

Model	3/8" Capacity	Swivel Pressure Rating	Inlet	Outlet
DHR50100D	100 Ft.			
DHR50150D	150 Ft.	5000 PSI	3/8" NPT-M	3/8" NPT-F
DHR50200D	200 Ft.			

MAXIMUM TEMPERATURE RATING: 185°F



	ltem			
	1	2	3	
DHR50100D	100056	2103051	2702006	
DHR50150D	100056	2103051	2702009	
DHR50200D	100056	2103051	2702050	
2100278	SWIVEL REPAIR KIT			