

Dimension Orifice des jets	PRESSION AU POUCE CARRÉ														
	500 PSI	600 PSI	700 PSI	800 PSI	1000 PSI	1500 PSI	2000 PSI	2500 PSI	3000 PSI	3500 PSI	4000 PSI	4500 PSI	5000 PSI	5500 PSI	6000 PSI
3.0	1.1	1.2	1.3	1.4	1.5	1.8	2.1	2.4	2.6	2.8	3.0	3.2	3.4	3.5	3.7
3.5	1.3	1.4	1.5	1.6	1.8	2.2	2.5	2.8	3.1	3.3	3.5	3.7	3.9	4.1	4.3
4.0	1.4	1.6	1.7	1.8	2.0	2.5	2.8	3.2	3.5	3.7	4.0	4.2	4.5	4.7	4.9
4.5	1.6	1.7	1.9	2.0	2.3	2.8	3.2	3.6	3.9	4.2	4.5	4.8	5.0	5.3	5.5
5.0	1.8	1.9	2.1	2.2	2.5	3.1	3.5	4.0	4.3	4.7	5.0	5.3	5.6	5.9	6.1
5.5	1.9	2.1	2.3	2.5	2.8	3.4	3.9	4.3	4.8	5.1	5.5	5.8	6.2	6.4	6.7
6.0	2.1	2.3	2.5	2.7	3.0	3.7	4.2	4.7	5.2	5.6	6.0	6.4	6.7	7.0	7.3
6.5	2.3	2.5	2.7	2.9	3.3	4.0	4.6	5.1	5.6	6.1	6.5	6.9	7.3	7.6	8.0
7.0	2.5	2.7	2.9	3.1	3.5	4.3	4.9	5.5	6.1	6.5	7.0	7.4	7.8	8.2	8.6
7.5	2.7	2.9	3.1	3.4	3.8	4.6	5.3	5.9	6.5	7.0	7.5	8.0	8.4	8.8	9.2
8.0	2.8	3.1	3.4	3.6	4.0	4.9	5.7	6.3	6.9	7.5	8.0	8.5	8.9	9.4	9.8
9.0	3.2	3.5	3.8	4.0	4.5	5.5	6.4	7.1	7.8	8.4	9.0	9.6	10.1	10.6	11.0
10	3.5	3.9	4.2	4.5	5.0	6.1	7.1	7.9	8.7	9.4	10.0	10.6	11.2	11.7	12.2
12	4.2	4.6	5.0	5.4	6.0	7.3	8.5	9.5	10.4	11.2	12.0	12.7	13.4	14.1	14.7
15	5.3	5.8	6.3	6.7	7.5	9.2	10.6	11.9	13.0	14.1	15.0	15.9	16.8	17.6	18.4