




MADE BY ZEN®



RAYA

Solid Bamboo Aroma Diffuser
with soft ambient lighting

TABLE OF CONTENTS:

A. ABOUT THE RAYA

B. TECHNICAL SPECIFICATION

C. OPERATING INSTRUCTIONS

D. FEATURES

E. MAINTENANCE




F. TROUBLESHOOTING

G. WARRANTY

Congratulations on purchasing your MADE BY ZEN® Raya Bamboo Aroma Diffuser. Please keep this manual to help you get the most out of your Raya and for maintenance.

A - ABOUT RAYA

Crafted from sustainable bamboo, the Raya Aroma Diffuser fills your space with calming mist and a soft ambient glow. Its natural finish and refined shape bring quiet, eco-conscious elegance to any room. Designed for modern wellbeing, Raya is ideal for mindful rituals, gentle resets or everyday serenity. A beautiful blend of nature, scented mist and soft lighting, Raya transforms your space with effortless style.

 Ambient Lighting	Warm ambient LED lighting which can help you to relax: > Soft glow, fixed ambient light > Sleep mode (no light) option
 Mini Humidifier	Releases a humidifying mist. Ideal for counteracting some of the dryness created by today's central heating and air conditioning systems.
 Auto Shut Off	Safety feature (operates only when using mist function).


Thank you for purchasing Raya – where calm meets conscious design.

B - TECHNICAL SPECIFICATIONS

Model Name: Raya Aroma Diffuser

Model No.: EWMD095-2M

Power: 12W



IMPORTANT NOTES BEFORE USE:

The Aroma Diffuser **MUST** be cleaned before and after each use. When stored the unit should always be kept clean and dry. **NEVER** leave stagnant oil and water in the water tank for any prolonged period.



Whilst using your diffuser, you MUST clean the water tank every 3 days:

Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can develop in the water reservoir, and expelled into the air when next used causing very serious health risks. To prevent this the water tank **MUST** be cleaned properly every 3 days.

Der Aromadiffuser MUSS vor und nach jeder Verwendung gereinigt werden. Das Gerät sollte immer in einem sauberen und trockenen Zustand gelagert werden. Lassen Sie **NIE** über einen längeren Zeitraum Öl und Wasser im Wassertank stehen.

Während der Verwendung Ihres Diffusers **MÜSSEN** Sie den Wassertank alle drei Tagen reinigen:



Eventuell im Wasser oder der Umgebung, in der das Gerät verwendet bzw. gelagert wird, vorhandene Mikroorganismen können sich im Wassertank weiterentwickeln, bei der nächsten Verwendung in die Luft austreten und somit äußerst ernsthafte Gesundheitsrisiken hervorrufen. Zur Vermeidung dessen MUSS der Wassertank alle drei Tage ordentlich gereinigt werden.

يجب تنظيف الفواحة العطرية قبل وبعد كل استعمال. في حال حفظ وتخزين الجهاز يجب دوماً المحافظة عليه نظيفاً وجافاً. لا تترك بقايا الزيت والماء الراكد أيضاً في خزان الماء لمدة طويلة جداً.

أثناء استعمال الفواحة العطرية، يجب عليك تنظيف خزان الماء كل ٣ أيام.



يمكن للكائنات الدقيقة التي قد تكون موجودة في الماء أو في البيئة في حال استخدام الجهاز أو تخزينه أن تلمو في خزان الماء، وتنتشر في الهواء، وسوف يتسبب الاستعمال التالي للجهاز بأخطار صحية خطيرة جداً. لحماية خزان الماء، يجب تنظيفه على نحو ملائم كل ٣ أيام (٧٢ ساعة).

Place the Aroma Diffuser on a flat surface, at least 60cm away from the floor and at least 10cm away from the wall. DO NOT place the Aroma Diffuser on wooden or polished furniture that may be damaged by water moisture.

Always unplug the Aroma Diffuser from the electrical supply when cleaning or filling with water. Always use the power adaptor supplied. Ensure the cable is secure to avoid tripping or knocking over the Aroma Diffuser. If the power adaptor is damaged, it must be replaced with a suitable adaptor provided by the manufacturer or its agent. Alternatively, a new adaptor can be purchased from your retailer.

Use a suitable measuring cup to fill the water into the water tank. Never attempt to fill water under a running tap or whilst plugged in. Do not fill the water beyond the max water level line. If overfilled, carefully remove the excess water from the tank in the 'drainage direction' as shown by the arrow and away from the vent hole.

The Aroma Diffuser must be kept out of reach from children and pets to avoid risk of injury. Children should be supervised at all times to ensure they do not play with the appliance.

The Aroma Diffuser is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Keep the Aroma Diffuser in a clear space to allow the mist to freely spread and away from appliances especially those sensitive to water to avoid unnecessary accidents.

The Aroma Diffuser must be cleaned after each use and should always be kept clean and dry when not in use. Never leave stagnant oil and water in the water tank for prolonged periods.

Never attempt to disassemble your Aroma Diffuser or repair the product, as this will void your warranty and create a shock hazard. Contact your retailer if an internal inspection is required.

In case of abnormal observations such as smoke, peculiar smells or noise, stop using the Aroma Diffuser immediately and contact the retailer from where you purchased it. Never wrap the aroma diffuser or adaptor with cloth or paper as blocking ventilation could increase the risk of fire.

Always handle the Aroma Diffuser with care - accidental damage is not covered under the warranty.

Always use water at room temperature and use only fresh, clean water from a reliable source. Do not fill the water tank with other chemicals or liquids other than water and a few drops of fragrance or essential oils.

Never touch the water within the water tank when the diffuser is in operation as the water may become warm. It is perfectly normal for the water temperature to increase over time. Especially if it has been running for a few hours. This is caused by the energy created from the vibrating disc. The water should not exceed 40°C but for some models it can increase to 50°C (+/- 5°C). However, as the mist dissipates from the mist outlet, the water temperature cools rapidly due to the large surface area of each droplet, hence the mist is referred to as a 'cool mist'.

Always plug the adaptor into the DC jack before plugging into the mains.


NEVER touch the ultrasonic ceramic disc while the diffuser is plugged in as this could cause serious injury.

Do not touch, plug or unplug the aroma diffuser with wet hands.


Do not immerse the unit in water or other liquids and do not attempt to clean in a dishwasher.

Keep away from open flames, extended exposure may create risk of explosion.
Store at room temperature.


C - OPERATING INSTRUCTIONS




Place the diffuser upright on a firm and flat surface. Remove the wooden cover carefully as shown.




Plug in the DC jack.




Add tap water to the water reservoir using a suitable filling cup, to the max. level line (max. 100ml).



Add 3-5 drops of your favourite fragrance or essential oil into the water.



Place the cover back on the diffuser and plug the adaptor into the power source.



Note: Do not lean or move or attempt to empty or refill the diffuser during operation.

BUTTON FUNCTIONS

To switch on the aroma diffuser, gently place your hand over the bamboo cover as illustrated on the direction of the on/off button located on the base of the unit.

The button position is highlighted with a tab on the base which can be removed before use.


Note: The Raya Aroma Diffuser is designed with a “click” sound that indicates the switch is functioning when pressed.

> **Press once** and the Aroma Diffuser and light will switch on.


> **Press twice** and the light will turn off (sleep / no light mode).

> **Press three times** and the Aroma Diffuser and light will switch off.

Note: The Aroma Diffuser will switch off automatically when the water level runs low.



CORRECT



INCORRECT

D - FEATURES

The Raya Ultrasonic Ceramic Aroma Diffuser provides a revolutionary way to fragrance your surroundings. It works by creating high frequency vibrations that breaks down the water and oil into minute particles which are then effectively diffused into the immediate surroundings.

Unique patented design.

Low energy LED lights.

Mini humidifier.


Aroma Diffuser: Can be used with ambient lighting or without the light, ideal for night time use.

Quiet operation.


Auto-shut off when water runs out for an additional safety.

Easy to clean and use.

E- MAINTENANCE INSTRUCTIONS



Make sure the unit has been switched off and unplug the DC jack and the adaptor from the mains.



Remove the bamboo cover carefully as shown.

**DO NOT EMPTY WATER FROM
THE SIDE OF THE AIR OUTLET**



Empty water via the drainage side as shown in the image avoiding water seepage into the air vent.



Use a clean swab or cloth to clean the unit.

Caution:

Always switch off the unit and disconnect the cable from the power source before cleaning.

Always keep your Aroma Diffuser clean and dry when not in use.

Never leave stagnant oil and water inside the tank for prolonged periods. If the aroma diffuser stops generating mist (or generates little mist), clean the ceramic disc as indicated above. For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

If the Aroma Diffuser does not generate mist (or generates little mist), clean the ceramic disc.

When cleaning, always take extra care to ensure water does not enter DC jack power port. Allow the unit to dry thoroughly as advised below if water accidentally enters the electrical port.

Accidental Leakage:

In the event of the aroma diffuser being knocked over during use, please follow the steps below to avoid malfunction.

- Unplug the diffuser from the mains and remove the cover carefully.
- Pour out any remaining water from the tank.
- Shake the diffuser gently to drain any water from inside, then leave for 24 hours for the diffuser to dry thoroughly in a well-ventilated area.

F - TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist or mist volume significantly reduced	Power supply is not connected.	Plug in the power adaptor and press the mist button on the base.
	Water is lower than the water level sensor.	Refill the tank with ordinary tap water. Take care not to fill past the max water level line.
	Water is exceeding the max water level line.	Carefully pour out excess water via the water drain side.
	There may be a build-up of oil on the ceramic disc.	Clean the ceramic disc with water and a clean cloth.
	Mist outlet is blocked.	Clean the mist outlet by thoroughly cleaning the inside of the cover with clean water. Ensure the ceramic cover is aligned correctly and not blocking the mist.
Unit will not switch on	There is insufficient water in the reservoir.	Carefully fill the reservoir with water to the max water level line. Do not overfill.
	The power cable may not be connected properly.	Disconnect the cable and try connecting properly.
Water is leaking from the product	The covers are not positioned correctly.	Remove the covers and replace correctly allowing mist to release correctly.
	The unit has been tipped or knocked over.	Follow the accidental leakage instructions.
	The temperature is low or there is high humidity.	Under these conditions the mist can sometimes condense into water droplets

The intensity and amount of mist may vary, but this is not unusual and should not be considered as a fault. Factors that may affect this include water type, humidity, temperature, air currents etc.

G - WARRANTY

This product carries a 12-month warranty for proper use in accordance with this manual against any manufacturing defects. Accidental damage is not covered under the warranty.

The warranty period is 12 months from the date of purchase. In case of any problems arising during the warranty period, please contact your retailer for maintenance or claims. Proof of purchase will be required, so it is vital that you keep your receipt of purchase with this safety manual.

Corrosive oils such as Citronella may cause damage to the unit if left in the water tank. This type of damage is not covered under the warranty. This Aroma Diffuser must be cleaned after each use.



IMPORTANT!

MADE BY ZEN® Ultrasonic Aroma Diffusers comply with the WEEE Directive (Waste from Electrical and Electronic Equipment Directive) 2012/19/EU.

When the Raya Aroma Diffuser reaches the end of its working life, it should not be disposed of in the normal waste stream, but at an appropriate collection point for the recycling of electrical products.

Caring for our planet is important to us, so please help us by disposing of Raya correctly. Thank you.



MADE BY ZEN®

MADEBYZEN.COM