



INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference

PACKAGE CONTENTS

- ▶ iGear ANC Pro Earbuds
- ▶ 350 mAh Charging Case Battery.
- ▶ Type-C Charging Cable
- ▶ Extra EarTips
- ▶ User Manual

SPECIFICATIONS

Bluetooth:

- ▶ Profiles: A2DP/AVDTP/AVRCP/HFP/SPP/SDP
- ▶ Version: 5.3 + EDR
- ▶ Chipset: JL
- ▶ Distance: 10 m

Earphones:

- ▶ Playtime: up to 4 Hours
- ▶ Battery Capacity: 2 x 35 mAh
- ▶ Sensitivity: 85 dB
- ▶ Driver: 10 mm
- ▶ Impedance: 32 Ω
- ▶ Frequency Response: 20 Hz ~ 20 kHz

Charging Case:

- ▶ Charge Input: 5V DC/1A
- ▶ Battery: 350 mAh
- ▶ Number of Recharges: 3
- ▶ Charging Time: 1.5 Hours

2

INSTRUCTIONS FOR USE

CHARGING THE CHARGING CASE

- ▶ Before using the earbuds for the first time, it is important to ensure that the battery of the charging case is fully charged.

- ▶ Take the provided Type-C charge cable and connect one end of it to the DC 5V charging slot on the charging case. Insert the cable firmly to establish a secure connection.

- ▶ Now, take the other end of the Type-C cable and connect it to a wall charger. Make sure the wall charger can provide a 5V output. Alternatively, you can connect the Type-C cable to an available USB port on a compatible device, such as a computer or a laptop.

- ▶ Once the cable is connected to a power source, the charging process will initiate. Look for a red LED indicator light on the charging case. The LED light is located on the front of the case.

- ▶ During charging, the red LED indicator light will blink. This blinking motion indicates that the charging process has begun, and power is being transferred to the charging case's battery.

- ▶ Keep the charging case connected to the charger until the LED indicator light stops blinking and remains solid red. This indicates that the battery of the charging case is fully charged.

Note: Remember to consult the device's user manual for any specific charging instructions or recommended charging times.

3

CHARGING THE EARBUDS

- ▶ Before using the earbuds for the first time, make sure that their battery is fully charged.

- ▶ Open the charging case and place the earbuds into their respective charging slots in the charging case. Make sure they are properly aligned and seated in the slots.

- ▶ Close the charging case. The earbuds will start charging automatically once the case is closed.

- ▶ Look for a blue LED light inside the charging case. When charging begins, the blue LED indicator light will turn on. This light indicates that the earbuds are receiving power and are being charged.

- ▶ Leave the earbuds inside the closed charging case until the charging is complete. The blue LED indicator light will turn off once the earbuds are fully charged.

Note the following important points:

- ▶ The charging time for the earbuds is approximately one (1) hour. Keep them in the charging case for this duration to ensure a full charge.

- ▶ While the earbuds are charging, they cannot be used. It is recommended to refrain from using them until the charging process is complete.

- ▶ The earbuds will automatically turn off when placed inside the charging case and the case is closed. This helps conserve battery power.

4

Note: Remember to consult the earbuds' user manual for any specific charging instructions or recommended charging times.

SWITCHING THE EARBUDS ON & OFF

Switching the Earbuds On:

- ▶ If the charging case is open, the earbuds will switch on automatically.

- ▶ In case the earbuds don't switch on automatically, you can manually switch them on by following these steps:

- Press and hold the Touch Control on one of the earbuds for about 5 seconds.

- As you continue to hold, you will see the blue and red LED indicator lights on the earbud start flashing.

- Once the LED lights start flashing, it indicates that the earbuds have powered on successfully.

Switching the Earbuds Off:

- ▶ To switch off the earbuds, follow these steps:

- Press and hold the Touch Control on either of the earbuds for about 5 seconds.

- As you continue to hold, you will notice the LED indicator lights on the earbuds turn off.

- Additionally, you will hear a voice prompt stating that the earbuds have been powered off.

5

Note the following important points: The earbuds have an inbuilt Smart Switch feature, which automatically powers them on when the charging case is opened and powers them off when the case is closed.

PAIRING WITH EACH OTHER

- ▶ Make sure both earbuds are turned off. If they are already on, you can turn them off by placing them back into the charging case and closing the case.

- ▶ Open the charging case. This will automatically turn on both earbuds.

- ▶ After powering on the earbuds, wait a couple of seconds. During this time, the earbuds will automatically pair with each other.

- ▶ Look for the LED indicator lights on both earbuds. They will start flashing red and blue, indicating that the earbuds are in the process of connecting to each other.

- ▶ Once the earbuds are successfully connected to each other, you will see a specific LED indication on each earbud:

- One earbud will have a slow blue LED flash, indicating that it is the primary earbud.

- The other earbud will have a red and blue LED flash, indicating that it is in Bluetooth pairing mode.

Note: If you want to use the earbuds individually, you can remove one earbud from the charging case at a time. Each earbud can be connected separately to a Bluetooth device.

6

PAIRING WITH BLUETOOTH DEVICE

- ▶ Ensure that the earbuds are charged and turned on by opening the charging case. The earbuds will automatically enter Bluetooth pairing mode when the case is opened.

- ▶ On the Bluetooth device you wish to pair with the earbuds, open the Bluetooth menu. The exact method may vary depending on the device, but it is typically found in the device's settings menu. If needed, refer to the device's user manual for specific instructions on accessing the Bluetooth menu.

- ▶ In the Bluetooth menu, you may need to select an option such as "Search for Devices" or "Add New Device" to start the pairing process. This allows the device to scan for available Bluetooth devices.

- ▶ Wait for the earbuds to appear in the list of available devices on your Bluetooth device. Look for the name "iGear-ANC Pro" in the list.

- ▶ Select "iGear-ANC Pro" on your device. Follow any additional prompts or instructions on your device's screen to complete the pairing process.

- ▶ Once the pairing is complete and a connection is established between the device and the earbuds, you will hear a tone or a prompt indicating that the earbuds are successfully connected.

Note: It is usually necessary to pair the earbuds with each Bluetooth device only once. After the initial pairing, the earbuds should automatically connect to the device when they are turned on and in range.

7

CONTROL

Function	Operation
Voice Assistant	Tap the left/right earbud Touch Control 4 times.
Play or Pause Track	Short press the left/right earbud Touch Control.
Next/Previous Track	Double Tap the left/right earbud Touch Control.
Volume+/Volume-	Tap the left/right earbud Touch 3 Times.
Answer/Hang up a Call	Short press Touch Control on either earbud to receive or disconnect a call.
Reject a call	Press and hold Touch Control on either earbud for 2 seconds to reject a call.
ANC ON/OFF	Press and hold Touch Control on earbud for 2 seconds.

WARRANTY

Warranty period: 1 Year
In case of consumer complaints:
Customer Care - +91 9372667193
Email: support@igear.asia
(Between 10am to 5pm, Mon-Fri)
www.igearworld.com

8



INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference

PACKAGE CONTENTS

- ▶ iGear ANC Pro Earbuds
- ▶ 350 mAh Charging Case Battery.
- ▶ Type-C Charging Cable
- ▶ Extra EarTips
- ▶ User Manual

SPECIFICATIONS

Bluetooth:

- ▶ Profiles: A2DP/AVDTP/AVRCP/HFP/SPP/SDP
- ▶ Version: 5.3 + EDR
- ▶ Chipset: JL
- ▶ Distance: 10 m

Earphones:

- ▶ Playtime: up to 4 Hours
- ▶ Battery Capacity: 2 x 35 mAh
- ▶ Sensitivity: 85 dB
- ▶ Driver: 10 mm
- ▶ Impedance: 32 Ω
- ▶ Frequency Response: 20 Hz ~ 20 kHz

Charging Case:

- ▶ Charge Input: 5V DC/1A
- ▶ Battery: 350 mAh
- ▶ Number of Recharges: 3
- ▶ Charging Time: 1.5 Hours

2

INSTRUCTIONS FOR USE

CHARGING THE CHARGING CASE

- ▶ Before using the earbuds for the first time, it is important to ensure that the battery of the charging case is fully charged.

- ▶ Take the provided Type-C charge cable and connect one end of it to the DC 5V charging slot on the charging case. Insert the cable firmly to establish a secure connection.

- ▶ Now, take the other end of the Type-C cable and connect it to a wall charger. Make sure the wall charger can provide a 5V output. Alternatively, you can connect the Type-C cable to an available USB port on a compatible device, such as a computer or a laptop.

- ▶ Once the cable is connected to a power source, the charging process will initiate. Look for a red LED indicator light on the charging case. The LED light is located on the front of the case.

- ▶ During charging, the red LED indicator light will blink. This blinking motion indicates that the charging process has begun, and power is being transferred to the charging case's battery.

- ▶ Keep the charging case connected to the charger until the LED indicator light stops blinking and remains solid red. This indicates that the battery of the charging case is fully charged.

Note: Remember to consult the device's user manual for any specific charging instructions or recommended charging times.

3

CHARGING THE EARBUDS

- ▶ Before using the earbuds for the first time, make sure that their battery is fully charged.

- ▶ Open the charging case and place the earbuds into their respective charging slots in the charging case. Make sure they are properly aligned and seated in the slots.

- ▶ Close the charging case. The earbuds will start charging automatically once the case is closed.

- ▶ Look for a blue LED light inside the charging case. When charging begins, the blue LED indicator light will turn on. This light indicates that the earbuds are receiving power and are being charged.

- ▶ Leave the earbuds inside the closed charging case until the charging is complete. The blue LED indicator light will turn off once the earbuds are fully charged.

Note the following important points:

- ▶ The charging time for the earbuds is approximately one (1) hour. Keep them in the charging case for this duration to ensure a full charge.

- ▶ While the earbuds are charging, they cannot be used. It is recommended to refrain from using them until the charging process is complete.

- ▶ The earbuds will automatically turn off when placed inside the charging case and the case is closed. This helps conserve battery power.

4

Note: Remember to consult the earbuds' user manual for any specific charging instructions or recommended charging times.

SWITCHING THE EARBUDS ON & OFF

Switching the Earbuds On:

- ▶ If the charging case is open, the earbuds will switch on automatically.

- ▶ In case the earbuds don't switch on automatically, you can manually switch them on by following these steps:

- Press and hold the Touch Control on one of the earbuds for about 5 seconds.

- As you continue to hold, you will see the blue and red LED indicator lights on the earbud start flashing.

- Once the LED lights start flashing, it indicates that the earbuds have powered on successfully.

Switching the Earbuds Off:

- ▶ To switch off the earbuds, follow these steps:

- Press and hold the Touch Control on either of the earbuds for about 5 seconds.

- As you continue to hold, you will notice the LED indicator lights on the earbuds turn off.

- Additionally, you will hear a voice prompt stating that the earbuds have been powered off.

5

Note the following important points: The earbuds have an inbuilt Smart Switch feature, which automatically powers them on when the charging case is opened and powers them off when the case is closed.

PAIRING WITH EACH OTHER

- ▶ Make sure both earbuds are turned off. If they are already on, you can turn them off by placing them back into the charging case and closing the case.

- ▶ Open the charging case. This will automatically turn on both earbuds.

- ▶ After powering on the earbuds, wait a couple of seconds. During this time, the earbuds will automatically pair with each other.

- ▶ Look for the LED indicator lights on both earbuds. They will start flashing red and blue, indicating that the earbuds are in the process of connecting to each other.

- ▶ Once the earbuds are successfully connected to each other, you will see a specific LED indication on each earbud:

- One earbud will have a slow blue LED flash, indicating that it is the primary earbud.

- The other earbud will have a red and blue LED flash, indicating that it is in Bluetooth pairing mode.

Note: If you want to use the earbuds individually, you can remove one earbud from the charging case at a time. Each earbud can be connected separately to a Bluetooth device.

6

PAIRING WITH BLUETOOTH DEVICE

- ▶ Ensure that the earbuds are charged and turned on by opening the charging case. The earbuds will automatically enter Bluetooth pairing mode when the case is opened.

- ▶ On the Bluetooth device you wish to pair with the earbuds, open the Bluetooth menu. The exact method may vary depending on the device, but it is typically found in the device's settings menu. If needed, refer to the device's user manual for specific instructions on accessing the Bluetooth menu.

- ▶ In the Bluetooth menu, you may need to select an option such as "Search for Devices" or "Add New Device" to start the pairing process. This allows the device to scan for available Bluetooth devices.

- ▶ Wait for the earbuds to appear in the list of available devices on your Bluetooth device. Look for the name "iGear-ANC Pro" in the list.

- ▶ Select "iGear-ANC Pro" on your device. Follow any additional prompts or instructions on your device's screen to complete the pairing process.

- ▶ Once the pairing is complete and a connection is established between the device and the earbuds, you will hear a tone or a prompt indicating that the earbuds are successfully connected.

Note: It is usually necessary to pair the earbuds with each Bluetooth device only once. After the initial pairing, the earbuds should automatically connect to the device when they are turned on and in range.

7

CONTROL

Function	Operation
Voice Assistant	Tap the left/right earbud Touch Control 4 times.
Play or Pause Track	Short press the left/right earbud Touch Control.
Next/Previous Track	Double Tap the left/right earbud Touch Control.
Volume+/Volume-	Tap the left/right earbud Touch 3 Times.
Answer/Hang up a Call	Short press Touch Control on either earbud to receive or disconnect a call.
Reject a call	Press and hold Touch Control on either earbud for 2 seconds to reject a call.
ANC ON/OFF	Press and hold Touch Control on earbud for 2 seconds.

WARRANTY

Warranty period: 1 Year
In case of consumer complaints:
Customer Care - +91 9372667193
Email: support@igear.asia
(Between 10am to 5pm, Mon-Fri)
www.igearworld.com

8



INSTRUCTION MANUAL

Please read these instructions carefully and retain for future reference

PACKAGE CONTENTS

- ▶ iGear ANC Pro Earbuds
- ▶ 350 mAh Charging Case Battery.
- ▶ Type-C Charging Cable
- ▶ Extra EarTips
- ▶ User Manual

SPECIFICATIONS

Bluetooth:

- ▶ Profiles: A2DP/AVDTP/AVRCP/HFP/SPP/SDP
- ▶ Version: 5.3 + EDR
- ▶ Chipset: JL
- ▶ Distance: 10 m

Earphones:

- ▶ Playtime: up to 4 Hours
- ▶ Battery Capacity: 2 x 35 mAh
- ▶ Sensitivity: 85 dB
- ▶ Driver: 10 mm
- ▶ Impedance: 32 Ω
- ▶ Frequency Response: 20 Hz ~ 20 kHz

Charging Case:

- ▶ Charge Input: 5V DC/1A
- ▶ Battery: 350 mAh
- ▶ Number of Recharges: 3
- ▶ Charging Time: 1.5 Hours

2

INSTRUCTIONS FOR USE

CHARGING THE CHARGING CASE

- ▶ Before using the earbuds for the first time, it is important to ensure that the battery of the charging case is fully charged.

- ▶ Take the provided Type-C charge cable and connect one end of it to the DC 5V charging slot on the charging case. Insert the cable firmly to establish a secure connection.

- ▶ Now, take the other end of the Type-C cable and connect it to a wall charger. Make sure the wall charger can provide a 5V output. Alternatively, you can connect the Type-C cable to an available USB port on a compatible device, such as a computer or a laptop.

- ▶ Once the cable is connected to a power source, the charging process will initiate. Look for a red LED indicator light on the charging case. The LED light is located on the front of the case.

- ▶ During charging, the red LED indicator light will blink. This blinking motion indicates that the charging process has begun, and power is being transferred to the charging case's battery.

- ▶ Keep the charging case connected to the charger until the LED indicator light stops blinking and remains solid red. This indicates that the battery of the charging case is fully charged.

Note: Remember to consult the device's user manual for any specific charging instructions or recommended charging times.

3

CHARGING THE EARBUDS

- ▶ Before using the earbuds for the first time, make sure that their battery is fully charged.

- ▶ Open the charging case and place the earbuds into their respective charging slots in the charging case. Make sure they are properly aligned and seated in the slots.

- ▶ Close the charging case. The earbuds will start charging automatically once the case is closed.

- ▶ Look for a blue LED light inside the charging case. When charging begins, the blue LED indicator light will turn on. This light indicates that the earbuds are receiving power and are being charged.

- ▶ Leave the earbuds inside the closed charging case until the charging is complete. The blue LED indicator light will turn off once the earbuds are fully charged.

Note the following important points:

- ▶ The charging time for the earbuds is approximately one (1) hour. Keep them in the charging case for this duration to ensure a full charge.

- ▶ While the earbuds are charging, they cannot be used. It is recommended to refrain from using them until the charging process is complete.

- ▶ The earbuds will automatically turn off when placed inside the charging case and the case is closed. This helps conserve battery power.

4

Note: Remember to consult the earbuds' user manual for any specific charging instructions or recommended charging times.

SWITCHING THE EARBUDS ON & OFF

Switching the Earbuds On:

- ▶ If the charging case is open, the earbuds will switch on automatically.