



ENSEMBLE


Wooden Soundbar



SPECIFICATIONS

Bluetooth version: 5.0+EDR
Speaker driver unit size: 2.5INCH
Output power: 20W
Speaker impedance: 4 Ohm
Frequency response: 150-18 KHz
Signal to noise ratio: ≥80dB
FM scan range: 87.5-108.0Mhz
Wireless range: 10 M
Max memory USB/SD: 32GB
USB charging: DC 5V
Battery capacity: 2400mAh
Charging via USB port (PC): 6 hours charging time

FUNCTIONS



OFF/ON: To turn ON/OFF the speaker.

DC 5V: Plug in the Micro USB end into the soundbar and the other end of the charging cable into a USB power socket.

USB SLOT: Used to read the Mp3 files in FAT32 format with maximum size of 32GB.

TF SLOT: Used to read the Mp3 files in FAT32 format with maximum size of 32GB.

PLAY/PAUSE: Under USB/TF/Bluetooth mode, short press to play and pause.

M: To change mode between USB/TF, Bluetooth, and FM radio

BLUETOOTH

The soundbar starts in Bluetooth mode by default. Search for the bluetooth pairing name 'iGear-Ensemble' and pair with the device to start playing music. Short press ► to play/pause. Press ◀◀ and ▶▶ for switching to previous and next. Long press ▶▶/+ or -/◀◀ to increase or decrease the volume.

USB/TF Card

Insert the TF/SD card into the slot, the soundbar will detect and start playing the MP3 format music automatically. Press ► to play/pause. Short press ◀◀ or ▶▶ for switching to previous or next. Long press ▶▶/+ or -/◀◀ to increase or decreased the volume

FM RADIO

Press the 'M' button to switch to FM Mode. Short press ◀◀ and ▶▶ to change between the saved channels.

Note: Long press the -/◀◀ and ▶▶/+ to decrease or increase the volume.

CHARGING

Please use the original charging cable to charge. Red LED turns on while charging.

Warranty Period: 1 Year
In case of consumer complaints:
Customer Care: +91 93726 67193
Email: support@igear.asia
(Between 10am to 5pm, Mon to Fri)