







ORBITER BAITCASTER **BC80**



To swap spools, there is a single silver screw located on the handle side sideplate, directly in front of the BAIT-CASTER 1.0 (L)/(R) printing.

Please loosen the screw by hand, or else gently use a flat-head screwdriver until completely loose.

Once the screw is completely loosened, the non-handle sideplate will twist off from the frame and you will have direct access to the spool assembly for maintenance/replacement.

Reel Icon Pty Ltd Trading as Alvey Reels Australia ABN 57 625 261 707 2-6 Antimony Street Carole Park Qld 4300 t: +61 7 3271 2844 f: +61 7 3271 2451 For more hints and tips on maintenance, please visit the **spare parts** page at **www.alvey.com.au**

e: info@alvey.com.au

USA Website - www. alveyus.com