

Care Sheet

Selfie Frame

HOLLER PRINT

This handy sheet holds the secret to nurturing your sign like it's the rarest, most temperamental houseplant you've ever owned. Remember, signs have feelings too! Give your sign the love and attention it deserves, and soon you'll be hearing it whisper sweet nothings to you in fresh ink. So, grab that green thumb and prepare to nurture your sign-baby like it's a part of the family.

Handling

Handle your selfie frame with care to prevent creases, dents, or other damage to the material.

Cleaning

Regularly clean the selfie frame with a mild detergent and water solution. Gently wipe the frame with a soft cloth or sponge to remove dirt, fingerprints, or stains.

Avoid Harsh Chemicals

Do not use abrasive or corrosive chemicals on the frame, as they can damage the print and material.

Graphic Protection

Protect the graphics on your selfie frame by keeping it away from sharp or abrasive objects that could scratch or damage the print.

UV Exposure

Minimize prolonged exposure to direct sunlight, as UV rays can cause fading of the graphics and reduce the frame's visibility.

Storage

When not in use, store your selfie frame in a cool, dry place to protect it from dust and potential damage.

Transportation

Handle the selfie frame with care when moving or transporting it to avoid damage. Store it securely during transit to prevent scratches and dents.

Inspection

Routinely inspect the frame for any signs of wear, such as fading, scratches, or damage to the graphics. Address any issues promptly.

Recycling

When you no longer need the selfie frame or it becomes damaged, dispose of it responsibly by recycling or following local disposal guidelines.

By following these care guidelines, you can ensure that your selfie frame remains in good condition, effectively serves its purpose, and continues to provide a fun and interactive experience. Regular maintenance and protective measures will extend the life of your selfie frame and maintain its professional appearance.