



MODERN LANTERN RETURN POLICY

We **ONLY** accept returns (for NON product related issues) in ALL of this original packaging, packed as it was received, including the shade in its original wrap if at all possible.

We do **NOT** cover the return shipping unless the product was damaged or has a technical issue. We only issue refunds once we receive and inspect your return, so unpack and repack with care. In most cases we only charge a modest 10% fee for return shipping and restocking.

Have an issue or need to request a return?

Contact us: support@modernlantern.com
(with your order number if possible)

Thanks for your business and consideration,
we appreciate you.

www.ModernLantern.com

Modern Lantern®

CORDLESS LIGHTING SOLUTIONS

RECHARGEABLE LAMP USER GUIDE

Thank you for your trust in our product and our brand. You are now the proud owner of a Modern Lantern Cordless Lamp.

We appreciate your order and if we can help with anything, please don't hesitate to reach out to us:
(682) 224-5351 • support@modernlantern.com

Stephen & Carrie

Please look for an opportunity to leave us a review, via automated email, in a couple of weeks. Valued at a 25% discount off any future parts order.

Your Lamp Box Contains: _____

- Lamp Body
- Lamp Shade
- Harp & Finial (For Some Models)
- 12V LED Bulb (12 volt specialty bulb)
- 12V Li-ion Battery (Part #: Li700019)
- UL Wall Charger

www.ModernLantern.com

USER INSTRUCTIONS - (USE ONLY MODERN LANTERN 12 VOLT LED BULBS)

Read all instructions before using your Modern Lantern

Thank you for purchasing our product! Follow these simple instructions and you should be all set to enjoy years of cord free use from your decorative table lamp.

WARNINGS

- **DANGER. To reduce the risk of electric shock, do not immerse this product in water. Do not place or store this product where it can fall or be pulled into a water source like a sink, tub, or pool.**
- **Do not place lamp on unstable surfaces**
- **Do not leave indoor lamp products in the outdoor elements**
- **Do not expose battery to extreme temperatures**
- **Do not tamper or puncture battery**
- **DO NOT USE if the battery has been dropped or damaged**
- **Do not recommend leaving the battery charging while unattended**
- **Unplug your wall charger when not in use**
- **Charge our Li-Ion battery using 120V US grounded outlet**
- **Use ONLY Modern Lantern's 12V LED bulb, battery, and charger**
- **Contact Modern Lantern with any technical assistance or replacement parts at: support@modernlantern.com**

INSTRUCTIONS FOR USE:

- 1) Plug the charger into a standard INDOOR grounded wall outlet.
 - 2) Plug the charger cord male end into the round hole on the back of the battery (marked with "CHARGE"). Wall charger should have a solid red light to indicate the battery is charging, and solid green once fully charged (approx. 4 hours).
 - 3) Once charged, unplug the charger and unplug the battery.
 - 4) Tip the lamp upside down to install the battery. With our logo facing out, line up BOTH sets of double arrow indicators on the battery in first, while carefully matching up the three small connectors inside the base with the battery. While the base of the battery's lip is in place flush across the bottom, press down on the battery (on the lock/clip side) until it sits completely flush with the bottom plate. It should "CLICK" closed. If not, the lock at the top of the battery can be pushed up with your finger until you hear/feel it "CLICK" into place. Ensure the battery is flush and LOCKED to the base plate so it does NOT fall out when uprighting the lamp for use.
 - 5) And now for the cool part! Position the lamp wherever you like and switch it on for up to 32+ hours of use anywhere (depending on model and bulb used).
 - 6) Once the bulb has dimmed (or flashes), switch off the lamp via the switch and repeat the recharging steps above. Keep in mind the bonus of purchasing an extra battery pack through us is you should never have any downtime, as one will always be ready.
- Optional 12V LED bulbs and parts are available on our website.
 - Your Lamps Battery Pack is: Part # Li700019

USER MAINTENANCE:

- Never pick up or carry lamp by the harp or finial.
- Do not operate in temperatures below 32° or above 100° F.
- Product should be kept away from heat sources.
- To clean the lamp, wipe with a damp cloth, do not use cleaners.
- Only replace bulb with Modern Lantern 12V LED bulb. Standard light bulbs will NOT work and will void our warranty.
- Use only Modern Lantern authorized replacement parts.
- **For our outdoor line, recommend moving indoors or under cover during extreme weather.** Do not leave the lamp where water may 'pool up' on outdoor tables. Always use the provided diffuser over the shade (under the finial) and make sure the bulb globe cover is securely in place, covering the socket to keep water and moisture out. Make sure the battery latch is securely 'locked'.
- For replacement parts e-mail us at: support@modernlantern.com or call: **682-224-5351**
- Please recycle your battery by calling: **1-800-8-BATTERY** or **1-877-2-RECYCLE** to find the nearest recycling center.

TROUBLESHOOTING:

- **If lamp is not operating.** Check to make sure the battery is fully charged and charger indicator is green. Check to ensure lamp's battery is SECURELY inserted into the lamp's base. Check and ensure LED bulb is securely fastened in the socket. Check and make sure the socket switch is turned on.
- On rare occasions the battery might need reset if the charger light blinks. Simply unplug the battery from the charger for a moment, then repeat the instructions looking for solid charger light.**
- **If lamp is operating but very dim or bulb flashes off, then on.** This is indicating that the battery is very near its performance limit and will require a full charge.

- **If I want more usable performance from my lamp or optional brighter bulb.** Purchase ONLY from Modern Lantern's website, www.modernlantern.com, email us, or call: **682-224-5351**.

- **If I want to take my lamp outside to enjoy it.** Great! but make sure you bring it back indoors with you. **If the lamp is branded "outdoor" it can be operated outside under normal conditions.**

WARRANTY:

Modern Lantern warrants this product is free from defects in workmanship for one year from the date of purchase. The rechargeable battery is warranted for one year from the date of purchase. The LED bulb is warranted for one year from the date of purchase. An order confirmation is required for all warranty claims. This warranty does NOT cover damages resulting from accident, misuse, leaving our indoor rated lamps in the outdoor elements, or any tampering with components to alter the performance of the product.

For returns, warranty, or repair contact Modern Lantern at:

support@modernlantern.com

or visit us at: www.modernlantern.com or call: **682-224-5351**

www.ModernLantern.com

Patents: www.ModernLantern.com/Patents. All rights reserved.