




Petromax

Assembly of the legs of the Gas Table:

ge45-s | ge45-s-30 | ge45-s-37
ge90-s | ge90-s-30 | ge90-s-37

 Do not operate your Petromax Gas Table if parts of it are defective or missing. It is important to observe all the instructions in the section **Safety instructions and warnings** in this manual.

Insert the support legs into the slots of the Gas Table, tighten them using the clamping levers and set up the Gas Table (Caution: the support legs can be inserted into the Gas Table at different angles).

The legs of the gas tables can be attached in such a way that the table stands straight even if the floor is uneven. To do this, simply do not push the desired leg all the way out, but push it correspondingly less and then screw it tight.

Make sure that you choose an even, stable and fireproof surface. Otherwise the long legs of the Gas Table could sink into the ground, making the table stand unevenly. The Gas Table can also be used without support legs.

