



### **Adjusting the Broiler Spark Igniter in a Propane Stove**

- 1) Locate the Broiler igniter in the oven. It is the curved metal rod protruding from a white ceramic post next to the broiler
- 2) Engage the igniter and observe. No spark whatsoever means it is not close enough and a faint white spark means too close. The spark should be a strong blue.
- 3) Using a pair of needle nose pliers, adjust the positioning of the metal rod. Be careful to gently move it as not to snap it off.
- 4) The tip of the sparker should be located underneath one of the output holes in the burner bar.