



AVIATION

PRODUCT INSTRUCTIONS
Model Number: 30M-R

Revised January 30, 2019



Bogert Aviation Round Gear Jack Pad Instruction Manual


Round Gear Jack Pad

TECHNICAL SPECS


- Cradle round landing gear safely.
- Cessna C-172RG, 177RG, 182RG, 210, T210, P210, and similar landing gear.
- Fits bottle jacks with 1.25" diameter ram
- Adjusts to gear angle
- **Sold as singles**
- Made in the USA

Model Number	Qty	Description
30M-R	1	Round Gear Jack Pad Assembly





The warnings, precautions, and instructions discussed in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that common sense and caution are factors, which cannot be built into this product, but must be supplied by the operator.



Cautions:

- Support the axle anytime the wheel is removed with a suitable axle stand or blocking. (Bogert Aviation 17M-LGSS, Landing Gear Safety Stand)
- Do not allow anyone to climb on or get into the aircraft while supported by a jack.
- “WARNING” Study, understand and follow all instructions before operating this device.
- Lifting device only.
- Intended use is for lifting part of a total aircraft, only one wheel or axle at a time.
- Immediately after lifting, support aircraft with appropriate means.
- Do not exceed rated capacity. Use only on hard, level surfaces capable of sustaining rated capacity loads.
- Lift only on those areas of the vehicle as specified by the vehicle manufacturer.
- Ensure that the lift point is properly centered on the jack saddle.

Always wear safety glasses when using this equipment.

For more information, see our You-Tube Videos at
<https://www.youtube.com/user/BogertAviation>
Or search for Bogert Aviation.

*Climbing on Course
Since 1983*



BOGERT AVIATION INC.
3606 N Swallow Ave Ste 100
Pasco, WA 99301 USA
(509) 736-1513 Phone
(800) 627-8088 Toll Free
(509) 272-0280 Fax
www.bogertaviation.com
info@bogert-av.com

