

Unpacking and Repacking Instructions: IB370

Part 1 (Unpacking)

1. Open the box carefully by cutting the tape from both ends and top. Be sure to not cut too deeply.



2. Once opened remove the cardboard pieces as shown in the following pictures.



3. Next remove the two square cardboard pockets on either side of the machine base.



4. With assistance remove the InBody, keeping the machine horizontal to the ground at all times.



Part 2 (Repacking)

1. Lower the neck of the InBody to the horizontal position. Open the box and view the cutout portion for the base of the InBody.



2. With assistance place the base of the machine into the cutouts keeping the InBody horizontal to the ground.



3. Replace the two square pockets on either side of the machine.



4. Replace the cardboard covers as shown in the following pictures.



5. The repackaged unit should look as follows.



6. Be sure to tape the top and both ends securely to protect during transit.

