



Are you using all of the paper on your receipt paper rolls?

Your receipt printer has a low paper sensor that only lets you know when you have about a quarter roll left. Here is a better way to let you know when the roll is almost depleted. Open the printer lid, remove the roll, and look for the crescent shaped sensor in the right or left side of the paper well. Place a small piece of white electricians tape over the sensor. The printer will now sense it always has plenty of paper. When the roll is almost empty you will start to see color on the edges of your receipts indicating the roll is almost empty. Install a new roll. See, we just saved you more money.

