

Pairing Instructions for ElectraFin Wireless Remote Control

Step 1 Turn OFF the ElectraFin Control Case (Battery box)

Step 2 Open up the box, and using a Phillips head screwdriver, CAREFULLY remove the 4 screws holding the silver lid covering the motor controller box.

NOTE – Be very careful to not lose 4 screws, and DO NOT touch any Exposed terminals inside the motor controller once cover is removed

Step 3 Connect the emergency cut-off leash to outer box connection.

Step 4 On the inside of Motor controller box, Depress and HOLD blue button in the corner. While STILL PRESSING down on blue button, partially close box lid and simultaneously turn on/off switch ON. Red light inside the small metal box will illuminate. As soon as the red light comes on, IMMEDIATELY release the blue button.

Step 5 Push the “Reverse” button on the remote while the red light is illuminated to pair the remote to the motor controller. The lit red light inside metal box should flash when “Reverse” is pushed and released, indicating successful pairing. Once that is done, turn the on/off switch OFF, then back ON, and test remote for pairing. Depress forward and reverse buttons and listen for audible click, or connect ElectraFin and try switches.

Step 6 Once pairing has been completed, replace cover, ensuring that no wires are obstructing the lid of the case when closing.

NOTE: If remote does not successfully pair, retry step 4-5.

Contact Current Drives Technical Support at 1-800-686-8592 or email sales@currentdrives.com with any questions.