

BASEBOARD BOOSTER™



READ AND SAVE THESE INSTRUCTIONS.

Baseboard Booster™ Safety Precautions

The Baseboard Booster™ when attached to the baseboard, **MUST BE PLUGGED IN AND THE RED POWER LIGHT MUST BE LLUMINATED.** If unplugged (or unpowered), the Baseboard Booster™ can block heat and force the heat back into your baseboard creating a potentially dangerous heat buildup and risk of fire, injury to persons, or death.

Remove Baseboard Booster™ from the baseboard if RED Power Light is off

Please read the included “Set Up Instructions” carefully

NOT for use on portable or free-standing electric baseboards

Due to heat fluctuations, the unit may occasionally cycle off and on

There will be a delay once the heating system turns on as the unit will wait until the baseboard achieves its optimal “turn on” temperature

The surface of the unit may be HOT, let cool prior to removing from baseboard

READ ALL OF THE INSTRUCTIONS BEFORE USING THE BASEBOARD BOOSTER™ (Referred to as the Product).

This owner’s guide and any additional inserts are considered part of the Product. They contain important information about safety, use and disposal.

Before using the Product, please familiarize yourself with all operating and safety instructions. Please keep all documents for future reference and pass these documents on, together with the Product, to any future owner. The most current Safety Instructions and documentation for the Product are available at www.baseboardbooster.com.

INTENDED USE: The Product is intended to circulate heated air in indoor living spaces only. The Product is not intended for commercial or industrial use. The Product is not intended for use in bathrooms, laundry areas, and similar damp locations. Manufacturer assumes no responsibility for damage or injury due to unauthorized use or Product modification. Failure to follow these directions will void the Product warranty. The Product is intended to be used only on baseboard heaters.

WARNING: This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructing concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Risk to Children and Impaired Persons - Extreme caution is required during the installation, operation, cleaning, and maintenance of this product by and around children 12 years of age and younger and anyone with reduced physical, sensory, or mental capabilities, and whenever the Baseboard Booster™ is left operating and unattended. Children should be supervised to ensure that they do not play with the appliance, its parts and packaging material.

INSTALLATION WARNING—THE BASEBOARD BOOSTER™ IS SUPPLIED WITH A SAFE, EXTRA LOW VOLTAGE POWER SUPPLY AS REQUIRED FOR CLASS III APPLIANCES.

USE ONLY THE POWER SUPPLY UNIT PROVIDED WITH THE APPLIANCE.

To reduce risk of fire, electrical shock, and injury to persons, observe the following:

- Do not use Product in areas where gasoline, paint, or flammable liquids are used or stored.
- Do not use Product in an RV, boat or during any application where battery power is converted to AC power.
- No part of the Product (the appliance, power cord, plug, packaging, etc.) should be placed near furnaces, fireplaces, stoves, or other high temperature heat sources.
- Do not use the Product on an elevated surface such as a window, shelf, or desktop. Use only while placed on a baseboard heat source. Operate only in the upright position.
- The Product, power supply, power cord and plug cannot come into contact with water. Do not use the Product on wet surfaces. Do not use the Product in a bathtub or shower or position Product where it may fall into a bathtub, laundry, swimming pool or other water container. Do not use the Product outdoors or expose it to weather or elements.
- Do not run the cord under carpeting. Do not cover the cord with throw rugs, runners, or similar coverings. Do not route under furniture or appliances. Arrange cord away from the traffic area and where it will not be tripped over. The cord should not hang over edges of counters or be placed where it can be crimped or closed in doors. Place Product near an easily accessible outlet so the product can be unplugged quickly during an emergency.
- Do not modify the Product with any aftermarket accessory.

SAFE USE WARNING— When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electrical shock, and

injury to persons. To reduce risk of fire, electrical shock, and injury to persons, observe the following:

- Use the Product only as described in these Safety Instructions. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always unplug the Product when not in use. Baseboard Booster™ does not recommend unattended and unsupervised use of this heat accelerator.
- Always plug Product directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip). Do not use Product on a surge-protected unit or Ground Fault Circuit Interrupted (GFCI) outlet.
- Before plugging the power cord into an electrical outlet, be sure that all electrical information on the rating label, including voltage, is compatible with your outlet's power supply.

WARNING: To reduce the likelihood of circuit overload, fire, and electric shock, do not operate with a solid-state speed device, such as a dimmer control switch. Use of this appliance on the same electrical circuit as another high energy use product, such as a vacuum cleaner, blender, variable speed fan or circular saw is not advised. Do not use the Product with a timer designed to automatically turn the unit on or off. Do not operate Product with a damaged cord or plug or after the Product malfunctions, has been dropped or damaged in any manner. Discard Product or return to the Best Baseboard Booster™ authorized service facility for examination and/or repair.

- Do not sit or stand on the Product.
- Never use the cord as a handle or otherwise yank, strain or stretch the power cord.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the Product.

- Check your Product cord and plug connections. A loose-fitting outlet can cause the plug to overheat or cause a fire. Be sure the plug fits tight in the outlet. Check frequently during use to make sure the plug and outlet are not hot. If so, discontinue using Product and have the outlet replaced by a qualified electrician.
- Never ignore the signs of an electrical problem, such as: warm outlet cover plates, sparks when plugging in or operating, lights flickering/dimming during operation. Immediately turn off and unplug the Product if any such problems are noticed. Contact a qualified electrician to investigate possible causes before operating the Product again.
- Before moving, repositioning, servicing, cleaning and when not in use, use the Product controls to set to “Quiet Mode” and then unplug. To disconnect from the outlet, grasp and pull only the plug. Also, power off and unplug if the Product will be left unattended for an extended period or during electrical storms.
- If the Product and other electrical products suddenly stop working at the same time, your home circuit breaker or fuse may have tripped due to an overload of power.

SERVICING WARNING—To reduce risk of fire, electrical shock, and injury to persons:

- Clean your Product regularly, only as is instructed in this manual. Prior to cleaning, turn off the power on your Product and unplug. Do not use gasoline, thinners, solvents, ammonia, or other chemicals for cleaning. Refer to the CLEANING instructions provided in Set Up Instructions.
- Do not open Product housing while the Product is plugged in. To avoid risk of shock, all service and/or repairs must be done by Baseboard Booster™ Authorized Service Center.

The contents of the Safety Instructions may differ slightly from the actual Product. Observe any additional supplements. **WARRANTY** We expect this product to be perfect. If you are not satisfied with this product, let us know. We are here to help at help@baseboardbooster.com, LLC. 99 Innovations,

LLC All company names and product names are trademarks of their respective owners.

READ AND SAVE THESE INSTRUCTIONS.