


WASAI®


4-Digit Combination Lock Use Instructions

Please keep the safe open, when you set the code.

Step 1. Factory preset code is 0-0-0-0, check the 0-0-0-0 aim at the indication line



**Factory preset code:
0-0-0-0**



Step 2. Insert the attached sharp tool into the code hole.



Step 3. Dial the number to turn to your desired password **one by one, then release the sharp tool**



Your desired password

9-9-8-7

Remember well your password, you can record it with a pen

Warning: During setting the password, please **hold up the sharp tool**. If you set two numbers as 1-2 then release the sharp tool, **stop setting code**, the password is 8-8-0-0. Please pay attention on it.



New password

8-8-0-0

If you want to change the password, please repeat above sets 1 to 3.