



Lil' Mynx Permanent Dance Pole Installation

Thank you for your purchase of the Lil' Mynx permanent dance pole. There are a few things to keep in mind when installing your permanent pole.

- Your pole is not supplied with mounting hardware. You must determine what hardware is best for your installation.
- Your pole will arrive 1-2 inches taller than the room you are placing it in. This is to insure best fit. Do not remove or loosen bottom plate.

Step 1 Remove upper mounting plate from pole and screw it into your pre-determined location using the mounting screws you have chosen for installation. Be sure that two of the mounting screws go into the joist in the ceiling.

Step 2 Measure from the floor to the inside of the upper flange where the pole will sit. You will need to subtract 1/8 of an inch to allow the pole to slide in.

Step 3 Measure the pole and mark for cut.

Step 4 Cut the pole with a hack saw/porta band/tube cutter at the pre-determined point. Be sure it is cut straight. *Keep in mind this is stainless steel and you will need the appropriate blade for cutting.*

Step 5 De-bur the tube on the outside as well as the inside and place the plug back inside.

Step 6 Now that the pole is cut to length, place the pole in the top mount and slide into place. Check to make sure the pole is level in two directions. Drill holes into the floor and put the screws you have determined appropriate in and tighten.

Step 7 Remove set screw from hubs and using a center hole punch dent the pole through the set screw hole. Drill a 1/16" – 1/8" hole in the pole through the set screw hole. Insert pointed set screw and tighten to lock pole in place.

Your pole is now ready for use. Please call with any questions 877-700-7467.