




12V PORTABLE TRAVEL OVEN USER MANUAL



KATRAVELO12 | KATRAVELO12GTS

TABLE OF CONTENTS

WHY KICKASS?	1
WARNINGS	1
WHAT'S INCLUDED	2
OPTIONAL EXTRA	2
OVEN OVERVIEW	3
SPECIFICATIONS AND FEATURES	4
SETUP	5
OPERATING INSTRUCTIONS	5

CONGRATULATIONS ON PURCHASING YOUR NEW KICKASS 12V TRAVEL OVEN


WHY KICKASS?

KickAss is focussed on bringing the luxury of home to the outdoors. Your one stop shop for 12V products. All of our products are designed to be plug and play for the ultimate camping experience.


WARNINGS

- The oven, its surfaces, racks and handle may become hot while in use. Precaution should be take while handling
- Ensure there is a minimum 10cm gap between the oven and flammable objects
- Do not cut or modify the wiring, doing so may void your warranty
- Do not attempt to disassemble the oven, doing so may result in damage
- It is the customers responsibility that the unit is adequately mounted within the vehicle
- Do not expose the oven to water
- The contents of this user guide is subject to change without notice.
- Copying of this manual, either in part or it's entirety, is forbidden. You are allowed to use this manual for your personal use. Any other use is forbidden without the permission of KickAss Products Pty. Ltd
- The images and sample screens shown in this manual are for illustrative purposes only, and may not be the exact same as the actual model.


WHAT'S INCLUDED




1 x 12 Volt Travel Oven



1 x Anderson to Cigarette Adapter
(not included: *KATRAVELO12GTL*)



Mounting Brackets



2 x Removable Shelves

OPTIONAL EXTRA




KickAss Travel Oven Stainless Steel Tray with Trivet
SKU: KAOVENTRAY

OVEN OVERVIEW

KATRAVELO12



KATRAVELO12GTS



SPECIFICATIONS AND FEATURES

Specification	KickAss 12V Portable Travel Oven	KickAss 12V Portable Travel Oven with Glass Door
External Size	332W x 275D x 188H	
Internal Size	268W x 252D x 252H	
Power	130W @ 12V	
Operating Voltage	10-15V DC	
Electrical Connection	Anderson Style Plug with Cigarette socket adapter	
Fuse Rating	15A	
Oven Material	304 Stainless Steel	
Insulation	Fiberglass Insulation	
Mounting Brackets	Included	
Max Temperature	180°C	
Oven Timer	1-120 Minutes	1-120 minutes with toggle override for unlimited cooking
Light	No	Yes with on/off switch
Door	Insulated Door	Double Glazed Glass Door
Thermometer	No	Digital Thermometer

SETUP

- The KickAss Travel Oven can simply be connected to a 12 volt power source by an anderson connector directly. Both Small ovens can also be connected to a cigarette socket using the included cigarette to anderson adapter.
- The KickAss Travel Oven comes with a pair of brackets that can be used to secure the oven to your vehicle or bench. Ensure there is a minimum 10cm gap between the oven and flammable objects

OPERATING INSTRUCTIONS

Important: The KickAss Travel Oven is not fan forced, please keep this in mind when considering cooking times and allow for a longer cooking period.

Cooking with the KickAss Travel Oven

1. Preheat the oven to the desired temperature. Max temperature is 180°C-200°C
2. Place food in the oven on the racks. Ensure you don't overload the oven. The oven temperature may drop when putting cold food in
3. When food is cooked, remove contents from the oven and turn off.

Oven Timer

1. If using one of the glass door ovens, to set the oven to permanently on, rotate the timer counter clockwise to the ON position. Alternatively, rotate the timer clockwise to set the desired cooking time. Range between 1-120 minutes.
2. Timer will make a noise when the set time has been reached.
3. To turn off the timer earlier, rotate anticlockwise until the timer makes a noise.

Oven Light

The glass door ovens are fitted with internal lights, these can be turned on and off using the little red switch. Note, when set to the on position the light will use approximately 0.8-1A, it is recommended to turn this off when not in use.

Opening and Closing the Oven

- The KickAss Travel Oven is fitted with a door latch allowing you to securely close the oven to prevent any loss of heat.
- The latch may become hot during use. Please ensure appropriate safety precautions are taken.

Oven Use

- It is important that the oven is not overloaded as this will extend cooking times.
- Food may be placed on the racks provided directly, using aluminum foil or baking trays/dishes.
- We don't advise placing food directly on the bottom of the oven unless you are able to check this consistently to prevent any burning.

THANK YOU FOR CHOOSING

KICKASS®

KickAss® is committed to providing you with the most up to date product information. As printed material is harder to update we have created an online user guide portal including videos, user guides and product tips so you can view or download the latest product information at any time. This also helps to save our environment which we are committed to just as much as we are committed to our customer service.



ONLINE USER GUIDES

To get started with this product, please visit
supportportal.kickassproducts.com.au
and search for your SKU code

OUR GUARANTEE

This KickAss® product comes with a 1 year warranty for your peace of mind. In the unlikely event this product fails when used according to our user guide, we will either repair or replace it. For full warranty terms and conditions on this product, please see the user guide at:

supportportal.kickassproducts.com.au

Customer Support

For any technical or warranty enquires please visit our customer service portal at:

supportportal.kickassproducts.com.au



KICKASS PRODUCT QUALITY

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Warranty does not cover products that have not been used in accordance with the KickAss® user guide or are outside the warranty terms and conditions.

QUESTIONS AND COMMENTS

Please visit us at **kickassproducts.com.au** or email us at **support@kickassproducts.com.au**