



KICKCHARGE 10K AND 20K



Model: KAPBANK10K and KAPBANK20K



PRODUCT SPECIFICATIONS KICKCHARGE10K

- Battery: 3.85V/10000mAh
- USB C Input: 5V/3A 15W Max
- Lightning Input: 5V/2.4A 12W Max
- USB C PD Output: 5V-3A/9V 2.22A 20W Max
- USB A Output: 5V/3A 15W Max
- Wireless Output: 5W, 7.5W
- Wired Charging Compatible Devices: All iPhone and Android Phones
- Wireless Charging Compatible Devices: iPhone 8, iPhone XS and XR, iPhone 11, iPhone 12, Galaxy Note 8,9 and10, S20 and S2.


PRODUCT SPECIFICATIONS KICKCHARGE20K

- Battery: 3.85V/20000mAh
- USB C Input: 5V/3A 15W Max
- Lightning Input: 5V/2.4A 12W Max
- USB C PD Output: 5V-3A/9V 2.22A 20W Max
- USB A Output: 5V/3A 15W Max
- Wireless Output: 5W, 7.5W
- Wired Charging Compatible Devices: All iPhone and Android Phones
- Wireless Charging Compatible Devices: iPhone 8, iPhone XS and XR, iPhone 11, iPhone 12, Galaxy Note 8,9 and10, S20 and S2.

IMPORTANT AND SAFETY INFORMATION

- Fully Charge the power bank before first use or if the unit has not been used for a long period of time.
- To Maximize battery life, it is highly recommended to fully charge your battery every three months.
- Do not attempt to disassemble or replace the battery or batteries.
- This unit is not intended for use by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge.
- Children must be always supervised when around this unit.

UNDERSTANDING YOUR POWER BANK



TO RECHARGE POWER BANK

- Connect the USB C to USB A cable (included in the pack) to a USB A wall charger, the power bank will then automatically start charging.
- Connect a USB C to USB C cable (not included in the pack) to a USB C wall charger, the power bank will then automatically start charging.
- Connect a USB C to Lightning cable (not included in the pack) to a USB C wall charger, the power bank will then automatically start charging.
- During charging, the LED indicators will flash to show charging status.
- When charging is complete, the LED indicator will remain on.

CHECKING REMAINING BATTERY CAPACITY

- Do not alter or remove the factory plates or identification labels.
- Do not disassemble the device.

| Led ● On / ○ Off | Remaining Capacity |
|------------------|--------------------|
| ● ○ ○ ○ | Less than 25% |
| ● ● ○ ○ | 25% to 50% |
| ● ● ● ○ | 50% to 75% |
| ● ● ● ● | 75% to 100% |



CLEANING INSTRUCTIONS

- Ensure the unit is switched off and disconnected from a power source before cleaning.
- Clean with a damp cloth only.
- Do not use any abrasive cleaners or harsh chemicals.
- Ensure all components are completely dry before storing the unit.

Kickass is a registered trademark of
Kickass Products Pty Ltd

Designed & Imported by
KickAss Products Pty Ltd
39 Iris Place, Acacia Ridge, QLD 4110
Australia

Made in China

