


TE 1300 L



Parts List Tuba Exchange TE1300L Euphonium

Diag. F	Part #	Description	
	1300-1	Bell	
	1300-2	Bottom Bow	
	1300-2A	Ferrule, Bell to Bottom Bow	
	1300-2B	Bottom Bow Guard	
	1300-3	1st Branch	
	1300-3A	Ferrule, Bottom Bow to 1st Br.	
	1300-3R	Guard Wire, 1st Branch	
	1300-4	"S" Branch, Lg. Side	
-	1300-4A	Ferrule, 1st Br. To "S" Tubing	
	1300-5	Main T. Sl. Outer Tube, Lg.	
	1300-6	Main T. Sl. Inner Tube, Lg.	
	1300-7	Ferrule and Socket, T. Sl. Lg.	
	1300-8	Main T.SI. Crook	
	1300-9	Main T. Sl. Brace Rod	
	1300-10	Ferrule and Socket, T. Sl. Sm.	
	1300-11	Main T. Sl. Inner Tube, Sm.	
	1300-12	Main T.Sl. Outer Tube, Sm.	
	1300-13	"S" Branch, Sm. Side	
	1300-13A	Ferrule, T. Sl. To "S" Branch	
	1300-14	4th Valve Tubing, Multi-bend	
	1300-14A	Ferrule. 4th Valve Casing to 4th Va	lve Tuhina
-	1300-15	4th T. Sl. Outer Tube, Short	TVC TUBING
	1300-16	4th T. Sl. Inner, Short	
	1300-17	Ferrule and Socket, 4th T. Sl. Short	-
	1300-18	4th Slide Crook	
	1300-19	4th T. Sl. Brace Rod (Same as #9)	
	1300-20	Ferrule and Sckt, 4th T. SI Long (sa	
	1300-21	4th T. Sl. Inner Tube, Long	ine don 17)
	1300-22	4th T. Sl. Outer Tube, Long	
	1300-23	4th Valve Tubing, Straight	
	1300-23A	Ferrule, 4th Tubing to 4th Valve	
	1300-24	Mouthpipe	
	1300-24A	Ferrule, Mouthpipe to 1st Valve	
	1300-25	Mouthpiece Receiver	
	1300-26	Brace, Receiver to Bell	
	1300-27	Brace, 1 Piece, Bell to 1st Branch	
	1300-28	Brace, 1 piece, 1st Branch to "S" To	ube Ferrule
	1300-29	Brace, 1 piece, Main T. Sl. To 3rd Sl.	
	1300-29A	Brace, 1 piece, 4th Tubing to Lg. "S	
	1300-30	Brace, 1 Piece, bet. 1st Outer AND	
	1300-31	Brace, 1 piece, bet. 2nd outer Slide	
-	1300-32	Brace Socket, for Bell	
	1300-33	Brace Socket, for Slide Tubing	
	1300-34	Brace Socket, for T. Sl. Lg Side (us	e #35)
	1300-35	Brace Socket, for 1st Branch	
	1300-36	Brace Socket, for SIIde Tubing (use	e #33)
-	1300-37	Brace Socket, for T. Sl. Small Side	/
	1	1	<u> </u>

Parts List Tuba Exchange TE1300L Euphonium

Diag.	Part #	Description	
	1300-38	Brace Rod, 1st Branch to 4th Tubing	
	1300-39	Brace Rod, Bell Braces (use # 38)	
	1300-40	Brace Rod, 1st Branch to 3rd Tubing (use #38)	
	1300-40	Brace Rod, 1st Branch to Main T. Sl. Small Side (use #38)	
	1300-41	Water Key	
	1300-42	Water Key Saddle	
	1300-43	,	
	1300-44	Water Key Spring Water Key Screw	
	1300-45	Water Key Screw Water Key Cork	
		3rd Slide Outer Tubes	
	1300-47		
	1300-48	2nd Sl. Outer Tube, Short	
	1300-49	2nd Sl. Outer Tube, Long	
	1300-50	1st Slide Outer Tubes	
	1300-51	1st and 3rd Slide, Inner Tubes	
	1300-52	Ferrules, 1st and 3rd Slides	
	1300-53	Crook, 1st and 3rd Slides	
	1300-54	2nd Slide Tube, inner, Short	
	1300-55	2nd Slide Tube, Inner, Long	
	1300-56	Ferrules, 2nd Slide	
	1300-57	Crook, 2nd Slide	
	1300-58	Pull Ring, 2nd Slide	
	1300-59	Valve Spring, All Valves	
	1300-60A	1st Piston	
	1300-60B	2nd Piston	
	1300-60C	3rd Piston	
	1300-60D	4th Piston	
	1300-61	Valve Guide	
	1300-62	Valve Guide Metal Washer	
	1300-63	Piston Stem	
	1300-64	Stem Felt	
	1300-65	Top Cap (old style, before serial #3899)*	
	1300-65A	Top Cap (serial #3900 and above)*	
	1300-66	Finger Button Felt	
2	1300-67	Finger Button	
2	1300-68	Bottom Cap (old style,before serial #3899)*	
2	1300-68A	Bottom Cap (serial #3900 and above)*	
2	1300-69	Valve Cluster Special Order - Call for Price	
2	1300-70	Water Key Assembly - includes #42,43,44,45,46	
	1300-71	Lyre Holder	
2	1300-72	Lyre Holder Screw	
		For Silver plated parts, add 30% to cost	
	* 1300S Euphs, old style caps before Ser.# 2899 1300S Euphs new stye caps Ser.# 2900 and above		