


TE-8232 Diagram 1



TE-8232 4/4 BB Flat Marching Tuba

Dia.	Part #	Description		
1	8232-01	Bell		
1	8232-02	Ferrule, Bell to Bottom Bow		
1	8232-03	Bottom Bow		
1	8232-04	Guard, Bottom Bow		
1	8232-05	Keel, Bottom Bow		
1	8232-06	Ferrule, Bottom Bow to First Branch		
1	8232-07	1st Branch Extension		
1	8232-08	Ferrule, Bottom Bow to 1st Br. Ext.		
1	8232-09	Guard, First Branch		
1	8232-10	Brace, 1 piece, 3rd Branch to First Branch		
1	8232-11	First Branch		
1	8232-12	Third Branch		
1	8232-13	Brace, 1 piece, Bell to 1st Branch		
1	8232-14	Brace, 1 piece, 1st Branch to #16 Ferrule		
1	8232-15	Ferrule, 1st Branch to 2nd Branch		
1	8232-16	Ferrule, 3rd to 4th Branch		
1	8232-17	Brace Socket, Mouthpipe T. Sl. To 1st Branch		
1	8232-18	Brace Rod, Mouthpipe T. Sl to 1st Branch		
1	8232-19	Brace Socket, 1st Branch to Mouthpipe		
1	8232-20	"S" Tube, 1st Valve to M T Slide (8232 only)		
1	8232-21	Fourth Branch		
1	8232-22	Brace, 1 piece, Bell to 2nd Branch		
1	8232-23	2nd Branch		
1	8232-24	Brace, 1 piece, 2nd Brnch to M. T. Sl, upper		
1	8232-25	Brace, 1 piece, 2nd Brnch to M. T. Sl, lower		
1	8232-26	Brace, 1 piece, 2nd Brnch, to 1st Br. Ext.		
1	8232-27	*Outer Tube, Main T.Sl.		
1	8232-28	*Inner Tube, Main T.Sl.		
1	8232-29	*Ferrule, Main T. Sl.		
1	8232-30	Crook, Main T.Sl.		
1	8232-31	Brace, 1 piece, B.B Ferrule to M. T. Sl.		
*	The parts indicated with asterisks have two or more uses on the instrument. (ie. Main Tuning Slide Tubes are identical) These parts are not supplied in pairs or sets. Order each individually			
All other parts identical to TE-8231				