



3

Plug the power cable into the diffuser then plug power point into the power socket.



4

Press the "POWER" button to switch the micro diffuser on.



SPECIFICATIONS

Size: 88 × 132mm

Weight: 400g

Input: AC 100 - 240V 50/60 Hz

Output: DC 5V 1A

Length of power line: 10cm

Spread Area: 100m³

Raw Material: Aluminum alloy PP

Accessories: USA AC Adapter, USA Cable, mist spray head, user manual, fragrance oil bottle, fragrance.

WARNING

Refill bottles contain pure concentrated fragrance and essential oils.

Keep out of reach of children at all times.

Keep upright: If the diffuser is knocked over the oil will leak out.

Do not consume or get oil on skin. In case of skin contact wash off with soap and water.

In case of ingestion seek medical advice.

In case of eye contact wash thoroughly with water and seek medical advice.

S HOME

MICRO DIFFUSER

Contact Us

Australia: 1300 731 680

International: +61 3 9943 8625


Email: info@scentaustralia.com.au

Web: www.scentaustralia.com.au

ABOUT US

Thank you for purchasing the Micro Scent Diffuser™ by Scent Australia. We are sure you will love our wonderful fragrance range! Please read these instructions for proper operation and maintenance of your diffuser.

INSTRUCTIONS





Step 1: Press the “POWER” button to switch on the micro scent diffuser.

Step 2: Press the “TIMING” button to set the running time: “on(continuous)/30/60/120 min”

Step 3: Press the “ON TIMING” button to set the scent on time “5/10/30/60 sec”

Step 4: Press the “OFF TIMING” button to set the scent off time “5/10/30/60 sec”

Note: The more “on time” vs “off time” the stronger the scent.



1

Insert the fragrance bottle into the mist spray head and tighten by turning counter clockwise.



2

Insert the fragrance bottle into the mist spray head and tighten by turning counter clockwise.

