



JIMMYJANE

Sell Sheets - Winter 2024

European Version

JIMMYJANE REIMAGINED

Elevate Your Intimate Experience With Our Electrifying
Collection of Innovative Pleasure Products!



Since its inception in 2004, **JIMMYJANE** has revolutionized the landscape and perception of sexual well-being. Built on the belief that pleasure is a source of power and that well-designed products contribute to overall well-being, we have consistently shown a commitment to innovation. By merging sophisticated product development with proprietary technology, we strive for a future where sensuality and technology converge seamlessly.

JIMMYJANE believes in the uniqueness of each individual's sexuality, designing products that encourage exploration and interpretation rather than dictating what is considered sexy. Celebrating our 20th anniversary in 2024, we reflect on a journey marked by creativity and a dedication to elevating intimate experiences.

As we enter our third decade, we stand as a guiding light of innovation in the adult industry, continuing to shape the future of pleasure with a rich legacy behind, and an exciting journey ahead. Our latest product launch seamlessly merges cutting-edge technology with sophisticated design, promising to redefine and elevate intimate experiences. We appreciate your interest in the brand, and we look forward to building our partnership with you for many years to come. As always, our commitment remains unwavering in delivering outstanding products and services. **After all—Your Pleasure is Our Passion!**



We are proud to announce a shift to using packaging certified by the Forest Stewardship Council (FSC).

Renowned for our avant-garde design, **JIMMYJANE** is proud to announce a shift to exclusively using FSC Certified packaging, aligning our products with environmentally responsible practices.

JIMMYJANE



CHECK OUT THE VIDEO



FORM 2[®] PRO

The best seller in pleasure is back—and more powerful than ever. Featuring a new magnetic USB charging cord with five vibration modes and five intensity levels, the Form 2[®] Pro's dual-motor design will powerfully massage, stimulate, and tease your clitoris, reaching new levels of euphoric climax.

KEY PRODUCT FEATURES

- Multi-award-winning design
- The unique, flexible design surrounds sensitive areas with concentrated vibrations
- Dual-motors offer powerful, fulfilling vibrations
- Choose from 25 vibration modes—5 vibration patterns with 5 intensity levels per pattern (5 x 5)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 90-minute charge time
- Waterproof: fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and stainless steel
- Easy 3-button operation
- 1-Year limited warranty

USAGE INSTRUCTIONS

Note - When first received, the Form 2 Pro should be locked, but if you see a flashing light when a button is pressed, follow the steps below to unlock the device.

Unlock - Press the power & "+" buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting the FORM 2 Pro to a powered charging cable will unlock it.

Lock - Press the power & "+" buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

Power ON - Press and hold the power button for three seconds to turn on the FORM 2 Pro. The LED will turn on for 3 seconds and then turn off—the massager will begin to vibrate in the constant vibration mode at medium speed.

Changing Modes / Speeds - Press the power button to cycle through the 5 vibration modes. The LED will turn on for 3 seconds, slightly mimic the current vibration mode, and then the LED will turn off.

Press "+" button to increase the speed on each mode. The LED will get slightly brighter, and will turn off after three seconds.

Press "-" button to decrease the speed on each mode. The LED will get slightly dimmer, and will turn off after three seconds.

Power OFF - Press and hold the power button (middle button) for three seconds to turn off the FORM 2.

CARE INSTRUCTIONS

Spray JimmyJane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

(1) FORM 2[®], (1) Travel Pouch, & (1) USB Charging Cord

PINK



SKU	JJ10901
UPC	840281300907



SLATE



SKU	JJ10904
UPC	840281300006



PRODUCT INFO

PRODUCT SPECS
Length: 3 in. (7.5 cm)
Width: 1.8 in. (4.5 cm)
Ear Length: 1.3 in. (3.2 cm)
Ear Diameter: 0.6 in. (1.5 cm)
PACKAGE SPECS
Width: 3.9 in. (10 cm)
Height: 7.5 in. (19.1 cm)
Depth: 2.2 in. (5.6 cm)
Weight: 6.2 oz. (175 g)
CARTON SPECS
24 pcs per carton
Width: 16.6 in. (42.2 cm)
Height: 8.4 in. (21.3 cm)
Depth: 13.8 in. (35 cm)
Weight: 14.6 lbs. (6.6 kg)

MODES
Modes: 5 x 5
IP RATING
IPX7
MATERIALS
Silicone & Stainless Steel
POWER SOURCE
Rechargeable Lithium Battery (USB + Magnetic Charging)
CHARGING INFO
Run Time: 60 min.
Charge Time: 90 min.

TESTERS AVAILABLE!



Tester Includes:
Full Product +
Informational
Table Tent

PINK	
SKU	JJ10901TE
UPC	840281325061



SLATE	
SKU	JJ10904TE
UPC	840281302505



RECYCLABLE - FSC CERTIFIED
MIX PACKAGING



APEX®

The Apex® is our best seller for a reason—it has everything you're looking for and more! First the silky-soft tongue is a toe-curling oral sex simulator that features seven patterns of simultaneous licking and vibration. Next, the 3-speed suction mode gently pulls and releases on your sensitive areas increasing blood-flow and bringing them close to the licking tongue. Finally, the curved handle contains a high-powered 10-function vibrating motor perfect for internal g-spot or anal pleasure, or external clitoral, nipple, and muscle stimulation. The silky-soft hygienic silicone handle and tongue feel great to the touch, and quickly adjust to body temperature.

When you want to go from vaginal play to nipple play, quickly switch the silicone rimmed cups and get back to the action! The high-performance, rechargeable battery controls the four powerful internal motors and stays strong from beginning to end. New to suction stimulation? Fear not! The Apex® also features a quick-release button that allows you to stop all suction immediately.

KEY PRODUCT FEATURES

- Multi-award-winning design
- A four-in-one pleasure package—Suction, licking + vibration, and handle vibration can be used to stimulate the clitoris, nipples, g-spot, anus, and more with concentrated sensations.
- 7 Powerful tongue licking + vibration modes—3 intensity levels and 4 patterns (3 + 4)
- 3 Intense "suck-and-release" power levels offer heightened pleasure by pulling sensitive areas close to the licking tongue.
- Vibrating handle can be used externally, as well as internally, and offers 10 vibration mode—3 intensity levels and 7 patterns (3 + 7)
- Quick release button allows you to quickly release the suction when desired
- Includes two cup attachments—The oval cup envelops the vulva, while the round cup encompasses the nipples (or even the head of a penis). The silky-soft silicone rims on both cups add a soft touch and help to ensure an air-tight seal
- Includes two textured tongue sleeves designed to tickle and tease
- Splashproof • Easy 4-button operation • 1-Year limited warranty



SKU	JJ40026
UPC	840281300884



PRODUCT INFO

PRODUCT SPECS	MODES
Length: 10.2 in. (25.8 cm) Width: 1.7 in. (4.2 cm) Depth: 1.7 in. (4.3 cm) Insertable (L): 4.8 in. (12.2 cm) Insertable (D): 1.4 in. (3.5 cm)	7 Tongue Patterns, 10 Handle Vibration Patterns 3 Suction Levels
PACKAGE SPECS	IP RATING
Width: 5 in. (12.7 cm) Height: 11 in. (28 cm) Depth: 2.8 in. (7 cm) Weight: 16.2 oz. (460 g)	IPX4
CARTON SPECS	MATERIALS
24 pcs per carton Width: 24.8 in. (63 cm) Height: 13 in. (33 cm) Depth: 18.1 in. (46 cm) Weight: 29.3 lbs. (13.3 kg)	Silicone, Stainless Steel, Polycarbonate, ABS, TPE
	POWER SOURCE
	Rechargeable Lithium Battery (USB + Magnetic Charging)
	CHARGING INFO
	Run Time: 60 min. Charge Time: 90 min.

USAGE INSTRUCTIONS

Note - When first received, the Apex should be locked. To unlock the device:

Unlock - Press the tongue & suction buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting the Apex to the powered charging cable will unlock it.

Lock - Press the tongue & suction buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

Power ON - Press the tongue, suction, or handle vibration buttons to activate the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.

Changing Modes / Speeds - Press the tongue, suction, or handle vibration buttons to cycle through modes. The LED will turn on and mimic the current vibration mode.

Power OFF - Press and hold the tongue, suction, or handle vibration buttons for 3 seconds to turn off.

Quick Release - To quickly release suction at any time, press and hold the suction release button. (Third button from the tongue)

CARE INSTRUCTIONS

Spray JimmyJane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

- (1) Apex®, (1) Vaginal Cup, (1) Nipple Cup,
- (2) Sleeves, (1) Travel Pouch, & (1) USB Charging Cord

TESTER AVAILABLE!



Tester Includes:
Full Product +
Informational
Table Tent

SKU	JJ40026TE
UPC	840281325078




RECYCLABLE - FSC CERTIFIED
MIX PACKAGING





REFLEXX™ RABBIT 1

The unique spring-like u-shape design of the Reflexx™ Rabbit 1 is more than just for looks—it's designed to hug your pelvic region and deliver the perfect amount of pressure. The curved shape and elongated handle allow you to comfortably move the massager to a multitude of angles, reaching the perfect spot every time. Both your g-spot and clitoris will be simultaneously sent into overdrive from the ultra-powerful, dual, independently controlled vibrating motors.

Want to take it to the next level? Indulge in the luxuriating "warming mode." Sit back, relax, and enjoy the warm embrace of the Reflexx™ Rabbit 1, even on the chilliest of days!

KEY PRODUCT FEATURES

- Ultra-powerful, dual, independently controlled, motors offer intense vibrations
- The unique, Reflexx™ action hugs the pelvic region, applying the perfect amount of pressure to stimulate the g-spot and clitoris simultaneously
- Warming mode brings the massager above body temperature in a few minutes
- Ergonomically designed handle increases your reach up to 6 inches
- Choose from 10 vibration modes per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 4-hour charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

USAGE INSTRUCTIONS

Note - When first received, the Reflexx Rabbit 1 should be locked. Follow the steps below to unlock.

Unlock - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

Lock - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

Power ON - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn on the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.

Changing Modes / Speeds - Press the G-Spot vibration or Clitoral vibration buttons to cycle through the 10 vibration functions. The LED will turn on, stay lit, and will blink to indicate the current mode. (Warming function has only one mode).

Power OFF - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn off. The LED will turn off.

CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

- (1) Reflexx™ Rabbit 1, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10303
UPC	840281301829



PRODUCT INFO

PRODUCT SPECS	MODES
Length: 6.6 in. (16.9 cm)	10 Vibration Patterns (3 + 7)
Width: 3.3 in. (8.3 cm)	1 Warming Mode
Depth: 1.7 in. (4.2 cm)	IP RATING
Insertable (L): 3.7 in. (9.5 cm)	IPX7
Insertable (D): 1.3 in. (3.4 cm)	MATERIALS
PACKAGE SPECS	Silicone, ABS Plastic
Width: 5 in. (12.7 cm)	POWER SOURCE
Height: 9.1 in. (23 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Depth: 2.8 in. (7 cm)	CHARGING INFO
Weight: 14.5 oz. (412.2 g)	Run Time: 45 min.
CARTON SPECS	Charge Time: 4 hours
24 pcs per carton	
Width: 15.7 in. (40 cm)	
Height: 11.6 in. (29.5 cm)	
Depth: 18.8 in. (47.7 cm)	
Weight: 23.4 lbs. (10.6 kg)	

TESTER AVAILABLE!



Tester Includes:
Full Product +
Informational
Table Tent

SKU	JJ10303TE
UPC	840281325139



RECYCLABLE - FSC CERTIFIED
MIX PACKAGING



SKU	JJ10305
UPC	840281301843



PRODUCT INFO

PRODUCT SPECS	MODES
Length: 9 in. (23 cm) Width: 3.4 in. (8.7 cm) Depth: 1.4 in. (3.6 cm) Insertable (L): 5.3 in. (13.7 cm) Insertable (D): 1.3 in. (3.4 cm)	10 Vibration Patterns (3 + 7) 1 Warming Mode
PACKAGE SPECS	IP RATING
Width: 5 in. (12.7 cm) Height: 9.1 in. (23 cm) Depth: 2.8 in. (7 cm) Weight: 12.3 oz. (350 g)	IPX7
CARTON SPECS	MATERIALS
24 pcs per carton Width: 15.5 in. (39.3 cm) Height: 11.6 in. (29.5 cm) Depth: 22.8 in. (58 cm) Weight: 20.2 lbs. (9.2 kg)	Silicone, ABS Plastic
	POWER SOURCE
	Rechargeable Lithium Battery (USB + Magnetic Charging)
	CHARGING INFO
	Run Time: 45 min. Charge Time: 3 hours

TESTER AVAILABLE!

Tester Includes:
Full Product +
Informational
Table Tent

SKU	JJ10305TE
UPC	840281325092

REFLEXX™ RABBIT 3

The unique, spring-like, curved design of the Reflexx™ Rabbit 3 is more than just for looks—it's designed to be reactionary to your movements. The internal steel band comes alive, reacting to the pressure that you apply, driving the powerful head vibrations deep down. This "Reflexx" action creates a one-of-a-kind experience, allowing you to move and press the massager to a multitude of angles to reach the perfect spot every time. Both your g-spot and clitoris will be simultaneously sent into overdrive from the dual independently controlled vibrating motors.

Want to take it to the next level? Indulge in the luxuriating "warming mode." Sit back, relax, and enjoy the warm embrace of the Reflexx™ Rabbit 3, even on the chilliest of days!

KEY PRODUCT FEATURES

- Dual independently controlled motors allow you to personalize your pleasure
- The unique, spring-like Reflexx™ action is reactionary to your movements—flexing when pressure is applied or released, giving the perfect amount of pressure.
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration modes per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 3-hour charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

USAGE INSTRUCTIONS

Note - When first received, the Reflexx Rabbit 3 should be locked. Follow the steps below to unlock.
Unlock - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.
Lock - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.
Power ON - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn on the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.
Changing Modes / Speeds - Press the G-Spot vibration or Clitoral vibration buttons to cycle through the 10 vibration functions. The LED will turn on, stay lit, and will blink to indicate the current mode. (Warming function has only one mode).
Power OFF - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn off. The LED will turn off.

CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

(1) Reflexx™ Rabbit 3, (1) Travel Pouch, & (1) USB Charging Cord



RECYCLABLE - FSC CERTIFIED MIX PACKAGING



HELLO TOUCH® PRO

Easily turn your fingertips into powerful pleasure devices. Simply pinch the base, and direct the silicone tip towards all of those spots that are yearning for attention, or slip the massagers into the silky-soft silicone finger sleeves and get creative with yourself or with a partner. That's not all—the travel case doubles as a rechargeable wireless remote, putting all the power in you, or your partner's, (free) hand.

When the fun is done, slide the massagers back into the travel case, and they'll be fully charged when it's time to play again.

KEY PRODUCT FEATURES

- Two mini finger massagers that pack a real punch
- Powered case charges the massagers while stored
- Rechargeable case doubles as a wireless remote for full control
- Includes two silicone sleeves that easily attach to your fingertips
- Case and massagers are USB rechargeable with the included magnetic charging cord
- High-performance battery: Massager: 25-min. run time / 90-min. charge time / Travel Case: 120-min. charge time
- Splashproof • Made with hygienic silicone and ABS plastic
- 1-Year limited warranty • Easy 1-button operation

USAGE INSTRUCTIONS

Standby Mode ON - Press and hold the power button on the bottom of the massager for three seconds to enter standby mode. The LED will turn on.

Power ON / Changing Modes / Speeds - Press the power button on the massagers or the remote case to cycle through the 10 vibration modes.

Power OFF - Press and hold the power button on the bottom of the massager or the remote case for three seconds to power off. The LED will turn off.

Standby Mode OFF - To turn standby mode off, press and hold the power button on the bottom of the massager for 3 seconds or insert the massagers into the remote case.

Charging Instructions - Both the massagers and the case can be charged with the magnetic charging cord. The remote case can recharge the massagers up to 2 times.

CARE INSTRUCTIONS

Spray JimmyJane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

- (1) Hello Touch Pro® Remote Case, (2) Massagers, (2) Silicone Finger Sleeves, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10525
UPC	840281301928



PRODUCT INFO

PRODUCT SPECS	MODES
Case Width: 2 in. (5.2 cm)	Modes: 10
Case Height: 3 in. (7.5 cm)	IP RATING
Case Depth: 1 in. (2.7 cm)	IPX6
Vibe Height: 2.4 in. (6.2 cm)	MATERIALS
Vibe Dia.: 0.7 in. (1.8 cm)	Silicone & Stainless Steel
PACKAGE SPECS	POWER SOURCE
Width: 3.9 in. (10 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Height: 7.5 in. (19.1 cm)	CHARGING INFO
Depth: 2.2 in. (5.6 cm)	Vibe Run Time: 25 min.
Weight: 7.1 oz. (200.8 g)	Vibe Charge Time: 90 min.
CARTON SPECS	Case Charge Time: 120 min.
24 pcs per carton	
Width: 12.4 in. (31.5 cm)	
Height: 9.6 in. (24.5 cm)	
Depth: 15.6 in. (39.5 cm)	
Weight: 11.6 lbs. (5.3 kg)	

TESTER AVAILABLE!

Tester Includes:
Full Product +
Informational
Table Tent

SKU	JJ10525TE
UPC	840281325122



CHECK OUT THE VIDEO



SKU	JJ10551
UPC	840281301850



PRODUCT INFO

PRODUCT SPECS	MODES
Length: 6.6 in. (16.9 cm) Width: 3.3 in. (8.3 cm) Depth: 1.7 in. (4.2 cm) Insertable (L): 3.7 in. (9.5 cm) Insertable (D): 1.3 in. (3.4 cm)	10 Vibration Patterns (3 + 7) (Per Motor) 3 Come Hither Speeds
PACKAGE SPECS	IP RATING
Width: 5 in. (12.7 cm) Height: 9.1 in. (23 cm) Depth: 2.8 in. (7 cm) Weight: 12.3 oz. (349 g)	Pulsus: IPX7 Remote: IPX4
CARTON SPECS	MATERIALS
24 pcs per carton Width: 15.8 in. (40 cm) Height: 11.6 in. (29.5 cm) Depth: 18.8 in. (47.7 cm) Weight: 20.1 lbs. (9.1 kg)	Silicone, ABS Plastic
	POWER SOURCE
	Rechargeable Lithium Battery (USB + Magnetic Charging)
	CHARGING INFO
	Plug Run Time: 45 min. Plug Charge Time: 120 min. Remote Run Time: 10 hrs. Remote Charge Time: 60 min.

TESTER AVAILABLE!



Tester Includes:
Full Product +
Informational
Table Tent

SKU	JJ10551TE
UPC	840281325108



PULSUS™ G-SPOT

The cleverly curved tip of the Pulsus™ G-Spot massager offers a 3-speed “come-hither” fingering motion that rocks the head back and forth, applying and releasing pressure and rubbing the G-spot and clitoris simultaneously. The dual, independently-controlled motors, each featuring ten high-performing vibration modes, are designed to powerfully stimulate your g-spot and clitoris together or solo. It’s a powerhouse of sensations that need to be felt to be believed.

The rechargeable Pulsus™ G-Spot Vibrator is designed with high-quality, super-soft, and phthalate-free silicone, because your health is just as important as your comfort, and you'll find both here.

KEY PRODUCT FEATURES

- 3-Speed “come-hither” fingering motions rock the head back and forth, applying and releasing pressure to the g-spot and clitoris simultaneously
- Dual, independently controlled motors allow you to personalize your pleasure
- Choose from 10 vibration options per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 120-minute charge time
- Waterproof; fully submersible and bath-friendly (Remote is not waterproof)
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

USAGE INSTRUCTIONS

Note - When first received, the Pulsus G-Spot should be locked. Follow the steps below to unlock.

Unlock - Press and hold the g-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

Lock - Press and hold the g-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

Standby Mode ON - Press and hold the power button on the Pulsus for 3 seconds to enter standby mode. The LED will turn on and stay solid.

Power ON - Once in standby mode, press the G-Spot vibration, Clitoral vibration, or come hither (power) buttons on the Pulsus or the remote to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

Power OFF - Press and hold the G-Spot vibration, Clitoral vibration, or come hither (power) for three seconds to turn off. The LED will turn off.

Standby Mode OFF - To turn standby mode off, press and hold the power button on the Pulsus. (The remote can only turn off functionality, not standby mode).

CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

- (1) Pulsus™ P-Spot, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



RECYCLABLE - FSC CERTIFIED MIX PACKAGING



DEIMOS®

High-tech pleasure meets intuitive design with our vibrating silicone Deimos® C-Ring. Complete with two powerful vibrating motors (one in each flexible ear) offering 3 intensity levels and 7 vibration patterns for maximum clitoral stimulation. Try out the remote control for spontaneous couples.

KEY PRODUCT FEATURES

- Two powerful motors, one in each flexible ear
- Choose from 10 vibration modes—3 intensity levels with 7 vibration patterns (3 + 7)
- Waterproof c-ring; fully submersible and bath-friendly (Remote is NOT waterproof)
- C-Ring and remote are both USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 120-minute charge time
- Made with hygienic silicone and plastic
- Easy 1-button operation
- 1-Year limited warranty

USAGE INSTRUCTIONS

Standby Mode ON - Press and hold the power button on the Deimos for 3 seconds to enter standby mode. The LED will turn on and stay solid.

Power ON - Once in standby mode, press the button on the Deimos or the remote to turn on. Press each of the buttons to cycle through their functions.

Power OFF - Press and hold the power button on the Deimos or remote for 3 seconds to turn off. The LED will turn off.

Standby Mode OFF - To turn standby mode off, press and hold the power button on the Deimos (the remote can only turn off functionality, not standby mode).

CARE INSTRUCTIONS

Spray JimmyJane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

PACKAGE INCLUDES

(1) Deimos®, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10705
UPC	840281300730



PRODUCT INFO

PRODUCT SPECS	MODES
Length: 4.1 in. (10.5 cm)	Modes: 10 (3+7)
Width: 2.2 in. (5.5 cm)	IP RATING
Depth: 1 in. (2.5 cm)	Deimos: IPX7
Ear Length: 1.3 in. (3.2 cm)	Remote: IPX4
Ear Diameter: 0.6 in. (1.5 cm)	MATERIALS
Remote Dia.: 1.5 in. (3.9 cm)	Silicone, ABS Plastic, & Stainless Steel
Remote Depth: 0.5 in. (1.2 cm)	POWER SOURCE
PACKAGE SPECS	Rechargeable Lithium Battery (USB + Magnetic Charging)
Width: 3.9 in. (10 cm)	CHARGING INFO
Height: 7.5 in. (19.1 cm)	Ring Run Time: 60 min.
Depth: 2.2 in. (5.6 cm)	Ring Charge Time: 120 min.
Weight: 6.6 oz. (186.4 g)	Remote Run Time: 10 hrs.
CARTON SPECS	Remote Charge Time: 60 min.
48 pcs per carton	
Width: 15.6 in. (39.5 cm)	
Height: 9.5 in. (24 cm)	
Depth: 24.4 in. (62 cm)	
Weight: 21.4 lbs. (9.7 kg)	

TESTER AVAILABLE!



SKU	JJ10705TE
UPC	840281325115



RECYCLABLE - FSC CERTIFIED MIX PACKAGING

PRODUCT HOLDER

Easily display most Jimmyjane products with this high-quality, plastic tester stand. Featuring a recessed hole in the base, and a harness on the top, most items will easily and securely lean in this holder, allowing them to be displayed prominently. If shelf space is at a premium, this display can also be hung on most standard slat wall with the built-in hook.

KEY PRODUCT FEATURES


- Easily holds a wide range of Jimmyjane products so you can display them next to boxes
- Features a hook on the back that will easily attach to slat wall

CARE INSTRUCTIONS

Spot clean with antibacterial cleaner and warm water. Allow to air dry.

PACKAGE INCLUDES

(1) Jimmyjane Product Holder

PRODUCT INFO	
SKU	PD4003-65
UPC	603912749526
	
CARTON SPECS	PRODUCT SPECS
1 pcs per carton	Length: 4.8 in. (12.2 cm)
	Width: 2.6 in (6.7 cm)
	Height: 4.5 in. (11.3 cm)
MATERIALS	
ABS Plastic	




JIMMYJANE PROMOTIONAL 3D HEADER SIGN

KEY PRODUCT FEATURES

- 3D sign that helps add depth to any slat wall layout
- Uses standard slat wall hooks that you already have to support and hold up the sign
- Patent pending fold out stand-offs means no sagging when hung
- Flat-packed making it easier to ship to stores

PACKAGE INCLUDES

(1) 90 cm 3D Sign

PRODUCT INFO	
SKU	SIGN3DJIMMYJANE
UPC	603912747690
	
PRODUCT SPECS	
Width: 35.4 in. (90 cm)	
Depth: 5 in. (12.7 cm)	
Height: 6 in. (15.2 cm)	
CARTON SPECS	
1 pcs per carton	



FORM 2 Pro - Pink

JJ10901



FORM 2 Pro - Pink
TESTER

JJ10901TE



FORM 2 Pro - Slate

JJ10904



FORM 2 Pro - Slate
TESTER

JJ10904TE



Apex

JJ40026



Apex
TESTER

JJ40026TE



Reflexx Rabbit 1

JJ10303



Reflexx Rabbit 1
TESTER

JJ10303TE



Reflexx Rabbit 3

JJ10305



Reflexx Rabbit 3
TESTER

JJ10305TE



Hello Touch Pro

JJ10525



Hello Touch Pro
TESTER

JJ10525TE



Pulsus G-Spot

JJ10551



Pulsus G-Spot
TESTER

JJ10551TE



Deimos

JJ10705



Deimos
TESTER

JJ10705TE



Product Holder

PD4003-65





3D Sign

SIGN3DJIMMYJANE



JIMMYJANE



