

Gleener® FURniture Brush™

INSTRUCTIONS



The Gleener FURniture Brush retrieves embedded pet hair from furniture, car interiors, carpets and other upholstered surfaces. It also doubles as a pet grooming tool; perfect for brushing and massaging your favorite four-legged friend.

1a Pop it On



1b



Hold the FURniture Brush in one hand with the Gleener Logo facing up. Hold the Ultimate Fuzz Remover in the opposite hand, also with the Gleener logo facing up.

(1a) Insert one corner of the Ultimate Fuzz Remover's lint brush head into the FURniture Brush cavity. (1b) Grasp the raised lower edge of the FURniture Brush and pull it over the other corner of the lint brush. It should be a snug fit.

2 Pile it Up



You're now ready to kick fur to the curb! Pick the offending surface and firmly brush away embedded pet hair.

Some fur will get trapped in the FURniture Brush bristles and the rest will mat together in little "pick-up-piles".

3 And Swipe it Away



To finish up the job, peel away the FURniture Brush and use the Ultimate Fuzz Remover's velvet lint remover to swipe away the "pick-up-piles".

Discard the icky fur or take a before & after pic and share it with us! You're now ready to enjoy your newly revitalized furniture!

Is your FURniture Brush installed correctly?



CARE AND STORAGE

After each use, give your FURniture Brush a bath to rid the bristles of dander and embedded pet hair. It's conveniently top-rack dishwasher safe and hand-washable with warm soapy water.

To clean the Ultimate Fuzz Remover's lint brush, simply rub your palm or thumb in the direction of the velvet brush's grain. The accumulated fur will roll right off.

Store your clean FURniture Brush with your Gleener Ultimate Fuzz Remover in the handy travel pouch provided. To preserve the integrity of your lint brush, we recommend removing the FURniture Brush from the handle prior to storage.

© 2015. Gleener® and the Gleener logo are trademarks of Gleener Marketing Inc., Montréal, Canada.

www.gleener.com

Gleener® Le Rebrousse-poil^{MC}

MODE D'EMPLOI



Le Rebrousse-poil de Gleener récupère les poils d'animaux logés dans les meubles capitonnés, les tapis, l'intérieur des automobiles, ainsi que dans la plupart des surfaces recouvertes. Il est aussi très efficace sur les couvertures, les lits pour animaux domestiques et de même que pour leur toilettage et les poteaux à griffes.

1a Insérer



1b



Tenez Le Rebrousse-poil dans une main, le logo de Gleener vers le haut. Prenez l'ultime antibouloche avec l'autre main, le logo de Gleener aussi vers le haut.

(1a) Insérez un coin de la brosse à charpie dans la cavité du Rebrousse-poil. (1b) Tirez délicatement l'autre coin de la brosse jusqu'à ce qu'il couvre la brosse à charpie de l'ultime antibouloche, pour un ajustement parfait.

2 Accumuler



Vous êtes maintenant équipé pour gagner la guerre contre les touffes de poils! Choisissez la surface à attaquer et brossez-la vigoureusement pour soulever les poils d'animaux.

Plusieurs touffes seront emprisonnées dans la brosse; le reste s'accumulera en petits tas.

3 et supprimer



Pour terminer, détachez Le Rebrousse-poil et retirez les résidus à l'aide de l'antipeluche en velours de l'ultime antibouloche.

Jeter les touffes infâmes. Prenez une photo avant et après votre séance de Rebrousage pour la partager avec nous. Vous pouvez maintenant profiter de votre meuble revivifié!

Avez-vous bien installé votre Rebrousse-poil?



ENTRETIEN ET RANGEMENT

Après chaque utilisation, trempez votre Rebrousse-poil dans l'eau pour débarrasser la brosse des poils et pellicules d'animaux. La nettoyer est si facile! Elle peut être lavée à la main avec du savon et de l'eau tiède ou encore, dans le lave-vaisselle (panier supérieur uniquement).

Pour nettoyer la brosse à charpie, frottez-la avec votre pouce ou avec la paume de votre main, dans le sens de la fibre du velours; les touffes accumulées se détacheront automatiquement.

Après l'avoir bien lavé, rangez votre Rebrousse-poil dans sa pochette de voyage avec son compagnon, le Gleener l'ultime antibouloche. Afin de garantir une meilleure longévité de votre brosse à charpie, nous suggérons fortement de détacher le Rebrousse-poil de la poignée avant le rangement.

© 2015. Gleener® et le logo Gleener sont des marques commerciales de Gleener Marketing Inc., Montréal, Canada.

www.gleener.com