

24419 – K-KOMPANION-6/24 Kodiak Kompanion Operating Instructions & Precautions

Charging: This product is rechargeable. For best performance, charge this light fully before first use. Plug the included charging cable into any USB power source. Peel back the rubber charging port cover on the light and connect the charging cable. The red charging indicator light turns green when charging is complete.

Operation: Repeatedly pressing the power button on the side of the light cycles between high and low brightness modes plus off. Long pressing the power button in any light mode selects the hyper bright mode.

Adjust the 6 position kickstand/handle to the desired angle. Other features include a carabiner clip (Carabiner Not Suitable for Climbing), strong integrated magnet and standard recessed tripod mount. **Please Note:** Place the included O-ring on the tripod screw before attaching the light to provide a more stable tripod mount.

Warning! This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use, do not use if parts are damaged, loose or missing.

Save these safety precautions.