

GOKONO

KB-950 USER GUIDE



CONGRATULATIONS

Thank you for choosing the KB-950 speaker.

Please read this manual fully to obtain the best results from your Rokono KB-950 speaker.

With the right care and attention it will give you many years of trouble free operation.

Package Contents

- Rokono KB-950 Bluetooth Speaker.
- 3.5mm line-in cable.
- Micro USB charging cable.
- User Manual.



CARE GUIDE

You can use your speaker whilst charging it, we recommend not charging your speaker all of the time however, as this will reduce the life of the battery.

Do not try to disassemble this device. Internal components can be damaged and sound quality will be reduced.



BUTTON GUIDE

1. **ON/OFF** Power and activate pairing.

2. Tap to **SKIP BACK**. Hold to reduce **VOLUME**.

3. Tap to **PLAY/PAUSE** and **ANSWER CALL**.

Long Hold to manually **MODE CHANGE**.

4. Tap to **SKIP FORWARD**. Hold to increase **VOLUME**.

5. Micro-SD Slot.

6. Aux-in.

7. Aux-out.

8. Micro USB Power-in (DC 5V Port).

9. USB Port.

LED STATUS

Power on and Searching	BLUE	Quick flash
Charging	RED	Solid
Fully Charged	OFF	OFF
Paired	BLUE	Slow flash
Playing	BLUE	Solid



CHARGING

- 1 Connect the small end of the Micro-USB charging cable to the speaker use DC 5V Port.
- 2 Connect the other end to a USB port on a computer or a suitable USB charger (max voltage 5V).
- 3 When charging the LED will turn solid RED.
- 4 Charging will take approximately 2-3 hours.



Not all USB ports can charge a device. Ensure that the LED on the speaker is solid RED when charging.



BLUETOOTH PAIRING

- 1 Turn the speaker on. It will automatically be in pairing mode (Blue LED flashing slowly.)
- 2 Activate your device Bluetooth search.
Select "Rokono KB950" when detected.
Should the device ask for a password, enter "0000".
- 3 For maximum volume turn the volume up on both your speaker **and** your device (phone/laptop/tablet) **after** pairing.



To connect your speaker to a different device you must first disconnect it in your device's Bluetooth settings.



WIRED CONNECTION

- 1 Insert one end of the 3.5mm Audio Jack cable into the speaker.
- 2 Connect the other end of the 3.5mm Audio Jack cable into your audio playing device (this will usually be the headphone socket.)
- 3 The speaker will automatically switch to play through the audio jack.
- 4 For maximum volume turn the volume up on both your speaker **and** your device (phone/laptop/tablet) **after** pairing.



Speaker buttons (Play, Forward, Back) only work with a Bluetooth connection.



HANDS FREE

Your KB-950 speaker has a built-in microphone for making and receiving phone calls.

If your mobile device is connected via Bluetooth and your phone rings, music playback will be interrupted.

Accept the call. Press the PLAY/PAUSE button.

End the call. Press the PLAY/PAUSE button.



The answer/end call button only works when connected using Bluetooth. When connected by cable answer the call on your phone.



MICRO-SD & USB PLAY

- 1 Turn the speaker on.
- 2 Insert the Micro-SD card or USB Flash Drive.
- 3 The LED status will change to green.
- 4 Press PLAY/PAUSE to start playback.

INTERNATIONAL

- GB.** Visit our website to download the full user guide.
- DE.** Besuchen Sie unsere Webseite in Bezug auf die vollständige Bedienungsanleitung zum Download.
- IT.** Visita il nostro sito web per scaricare il manuale utente completo.
- FR.** Visitez notre site Web pour télécharger le guide de l'utilisateur complet.
- ESP.** Visita nuestro sitio web para descargar el manual de usuario completo.

NEED HELP?

For more help and
friendly advice contact

support@rokono.com

PRODUCT REGISTRATION

Register your product online to
activate your Rokono guarantee.

www.rokono.com/register